



Haas
F1™ Team
OFFICIAL MACHINE TOOL

HAAS FACTORY OUTLET
A DIVISION OF PRODUCTIVITY INC

HAAS LATHE OPERATOR



OPERATOR MANUAL



This Manual is the Property of Productivity Inc

The document may not be reproduced without the express written permission of Productivity Inc, nor may it be sold. The content must not be altered, nor may the Productivity Inc name be removed from the materials.

This material is to be used as a guide to the operation of the machine tool. The Operator is responsible for following Safety Procedures as outlined by their instructor or manufacturer's specifications.

NOTE: Downloading and/or other use of this manual does not certify completion of the Training course. This manual is for reference only.

To obtain permission, please contact trainingmn@productivity.com.

For more information on
Additional Training Opportunities or our Classroom Schedules
Contact the Productivity Inc Applications Department

Minneapolis: ☎ 763.476.8600

Cedar Rapids: ☎ 319.734.3403

Omaha: ☎ 402.330.2323

Denver: ☎ 800-947-8665

Salt Lake City: ☎ 801.886.2221

Visit us on the Web: www.productivity.com

HAAS Interactive Mill Operator Manual

<https://www.haascnc.com/service/online-operator-s-manuals/lathe-operator-s-manual/lathe---introduction.html>

Note: Some of the content, images and screen shots included in this manual are taken from Haas manuals, controllers and web information with permission from Haas Automation Inc.
2800 Sturgis Road Oxnard CA 93030-8933

CONTENTS

Introduction to Basic Lathe Operation	7
Lathe MACHINING CENTER TRAVELS	8
HAAS Lathe Work Envelope	9
NEXT GENERATION CONTROL	11
Front Panel Controls	12
Pendant Right Side, and Top Panels.....	12
Pendant Top Panel	12
Icon Guide	13
KEYBOARD AND CONTROLS	21
Special Symbol Input.....	22
Function Keys	23
Cursor Key.....	23
Display Keys	24
Mode Keys	24
Numeric Keys	27
Alpha Keys.....	27
Lathe Jog Keys	28
Override Keys	29
Control Display	30
Tabbed Menu Basic Navigation	31
Input Bar	31
Mode, Key Access, and Mode Display.....	32
Network	33
Settings Display	34
Coolant Display	34
Offset Display	34
Position Display	34
Axis Display Selection	35
Current Commands	35
Devices – Mechanisms	36
Time Adjustment.....	40
Current Commands - Active Codes	40

Tools - Tool Usage	41
Macros Interface	42
ADVANCED TOOL MANAGEMENT	42
Allowed Limits	43
Tool Data	44
Plane	45
Calculator	45
Milling /Turning Calculator	47
Tapping Calculator	48
Media Display	48
Alarms and Messages Display	50
Add Messages	50
Maintenance	51
Load Calibration	51
Device Manager (List Program)	52
Device Manager Operation	53
File Display Columns	54
Check Mark Selection	55
Select the Active Program	55
Create a New Program	56
Edit a Program	57
Copy Programs	57
Create / Select Programs for Editing	58
Program Edit Modes	58
Basic Program Editing	59
Block Selection	60
Actions with a Block Selection	60
PART SETUP	61
JOG MODE	61
Tool Offsets	62
Set a Tool Offset	66
Work Offsets	68
Operation	69
Machine Power-On	69

Screen Capture.....	71
Error Report	71
Basic Program Search	72
Locate the Last Program Error	72
Safe Run Mode.....	73
Run-Stop-Jog-Continue	75
Graphics Mode	75
Lathe G-Codes Introduction	77
Lathe M-Codes Introduction.....	80
Lathe Settings Introduction	82
Lathe Other Equipment	87

[illegible]

INTRODUCTION TO BASIC LATHE OPERATION

Welcome to Productivity, Inc., your local Haas Factory Outlet (H.F.O.) for the Haas Lathe Operator Class. This class is intended to give a basic understanding of the set-up and operation of a Haas Turning Center.


In an "NC" (Numerically Controlled) machine, the tool is controlled by a code system that enables it to be operated with minimal supervision and with a great deal of repeatability. "CNC" (Computerized Numerical Control) is the same type of operating system, with the exception that a computer monitors the machine tool.

The same principles used in operating a manual machine are used in programming an NC or CNC Machine. The main difference is that instead of cranking handles to position a slide to a certain point, the dimension is stored in the memory of the machine. The control moves the machine to these positions each time the program is run.

The operation of the ST-Series Turning Center requires that a part program be designed, written, and entered to the memory of the control. Methods of file transfer are USB and Network.

To operate and program a CNC controlled machine, a basic understanding of machining practices and a working knowledge of math is necessary. It is also important to become familiar with the control console and the placement of the keys, switches, displays, etc., that are pertinent to the operation of the machine.

We will provide the Programming Manual on request to give everyone the opportunity to study G&M code lathe programming, but we also go over some programming basics in the class so that the operator can understand the programmer's intentions.



HAAS LATHE X AND Z AXES

THE MACHINE ILLUSTRATION SHOWS 2 DIRECTIONS OF TRAVEL AVAILABLE ON A LATHE MACHINE CENTER. NOW TO CARRY THE NUMBER LINE IDEA A LITTLE FURTHER, IMAGINE SUCH A LINE PLACED ALONG EACH SET OF TRAVELS (OR AXIS) OF THE MACHINE.






























X-AXIS MOVES THE TURRET AT AN ANGLE, UP AND DOWN, PERPENDICULAR TO THE SPINDLE.

Z-AXIS MOVES THE TURRET TOWARDS AND AWAY FROM THE SPINDLE.



LATHE WORK ENVELOPE COMPARISON

		CHUCK SIZE	DRAW TUBE	0"	10"	20"	30"	40"	50"	60"	70"	80"	Y-AXIS	APL	SUB-SPCL	ROBOT
A2-5	ST-10	6.5"	1.75"	12"Ø x 16"									●	●	●	●
	ST-10L	6.5"	1.75"	12"Ø x 32.5"									●	●	●	●
A2-6	ST-15	8.3"	2.5"	12"Ø x 16"									●	●	●	●
	ST-15L	8.3"	2.5"	12"Ø x 32.5"									●	●	●	●
	ST-20	8.3"	2.5"	13"Ø x 22.5"									●	●	●	●
	ST-20L	8.3"	2.5"	13"Ø x 42.5"									●	○	○	●
	ST-25	10"	3"	13"Ø x 22.5"									●	●	●	●
	ST-25L	10"	3"	13"Ø x 42.5"									●	○	○	●
	ST-30	10"	3"	15"Ø x 32.5"									●	○	●	●
	ST-30L	10"	3"	15"Ø x 62.5"									●	○	○	●
	DS-30Y	10"	3"	13.75"Ø x 32.5"									●	○	●	●
<div> Z-AXIS & TURNING DIAMETER CHUCK BAR CAPACITY </div>																

		CHUCK SIZE	DRAW TUBE	0"	10"	20"	30"	40"	50"	60"	70"	80"	Y-AXIS	APL	SUB SP/L	ROBOT
A2-8	ST-28	 12"	 4"										<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
	ST-28L	 12"	 4"										<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>
	ST-35	 12"	 4"										<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
	ST-35L	 12"	 4"										<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>
	ST-40	 15"	 4"										<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
	ST-40L	 15"	 4"										<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
		CHUCK SIZE	DRAW TUBE	0"	10"	20"	30"	40"	50"	60"	70"	80"	Y-AXIS	APL	SUB SP/L	ROBOT
A2-11	ST-45	 18"	 7"										<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
	ST-45L	 18"	 7"										<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
A1-20	ST-55	DUAL-CHUCK CAPABILITY	 12.5"										<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
 Z-AXIS & TURNING DIAMETER  CHUCK  BAR CAPACITY																

THE HAAS CONTROL

The industry's best CNC control keeps getting better.

Haas Automation's Control continues to prove itself as the machine tool industry's most user-friendly CNC control.

The Haas control is fast, smart, and powerful, with a simple user interface and consistent, intuitive navigation. For us, operator ease-of-use is always paramount, and our latest machines are packed with powerful features that simplify job setup and operation to make your shop more productive.

STANDARD CONTROL FEATURES:

- Dedicated Keypad
- One-Button Features
- Multi-Function Jog Handle
- 15" Color LCD Screen
- Ethernet Interface
- USB Port
- Advanced Tool Management
- 1 GB Memory
- Power-Failure Detection Module
- M130 Media Player
- HaasConnect Mobile Monitoring
- HaasDrop Wireless File Transfer
- WiFi Connectivity









INTUITIVE ONLINE HAAS NGC CONTROL

<https://www.haascnc.com/content/haascnc/en/service/online-operator-s-manuals/lathe-operator-s-manual/lathe---introduction.html>







OPERATOR'S AND SERVICE MANUALS

<https://www.haascnc.com/content/dam/haascnc/en/service/manual/operator/english---lathe-ngc---operator%27s-manual---2023.pdf>

FRONT PANEL CONTROLS

Name	Image	Function
POWER ON		Powers the machine on.
POWER OFF		Powers the machine off.
EMERGENCY STOP		Press to stop all axis motion, disable servos, stop the spindle and tool changer, and turn off the coolant pump.
HANDLE JOG		This is used to jog axes (select in HANDLE JOG Mode). Also used to scroll through program code or menu items while editing.
CYCLE START		Starts a program. This button is also used to start a program simulation in graphics mode.
FEED HOLD		Stops all axis motion during a program. The spindle continues to run. Press CYCLE START to cancel.

PENDANT RIGHT SIDE, AND TOP PANELS












Name	Image	Function
USB		Plug compatible USB devices into this port. It has a removable dust cap.
Memory Lock		In the locked position, this key switch prevents alterations to programs, settings, parameters, and offsets.
Setup Mode		In the locked position, this key switch enables all machine safety features. Unlock allows setup (refer to “Setup Mode” in the Safety section of this manual for details).
Second Home		Press to rapid all axes to the coordinates specified in settings 268 - 270. (Refer to “Settings 268 - 270” in the Settings section of this manual for details).
Auto Door Override		Press this button to open or close the Auto Door (if equipped).
Work light		These buttons toggle the internal work light and High Intensity Lighting (if equipped).






PENDANT TOP PANEL

Beacon Light

Provides quick visual confirmation of the machine’s current status. There are five different beacon states:










Light Status	Meaning
Off	The machine is idle.
Solid Green	The machine is running.
Flashing Green	The machine is stopped but is in a ready state. Operator input is required to continue.
Flashing Red	A fault has occurred, or the machine is in Emergency Stop












	Setup	Setup mode is locked; the control is in run mode. Most machine functions are disabled or limited while the machine doors are open.
	Setup	Setup mode is unlocked; the control is in setup mode. Most machine functions are available but may be limited while the machine doors are open.
	Bar feeder is not aligned	This icon appears when the bar feeder is enabled and out of position. Make sure the bar feeder is aligned with the feeding hole.
	Bar feeder cover is open	This icon appears when the bar feeder is enabled and the bar feeder cover is open
	Bar feeder is out of bars	This icon appears when the bar feeder has run out of the bars.
	Cycle door	The door must be cycled at least once to ensure that the door sensor is working. This icon appears after [power up] if the user has not yet cycled the door.
	Door open	Warning, door is open.
	Light curtain breach	This icon appears when the machine is idle, and the light curtain is triggered. It also appears when a program is running, and the light curtain is running. This icon disappears when the obstacle is removed from the light curtain line of sight.
	Light curtain hold	This icon appears when a program is running, and the light curtain is triggered. This icon will clear the next time [cycle start] is pressed.
	Running	The machine is running a program.
	Jog	An axis is jogging at the current jog rate.













	Jog warning	This icon appears when setting 53, jog w/o zero return, is set to on and the machine is in handle jog mode. note: setting 53, jog w/o zero return, is set to on automatically if apl hardware is installed and the machine has not been zeroed.
	Apl mode	This icon appears when the machine is in apl mode.
	Power saving	The power-saving servos-off feature is active. Setting 216, servo and hydraulic shutoff, designates the time allowed before this feature activates. Press a key to activate the servos.
	Jog	This icon appears while the control returns to the workpiece during a run-stop-jog-continue operation.
	Jog	You have pressed [feed hold] during the return portion of a run-stop-jog-continue operation.
	Jog	This icon prompts you to jog away during a run-stop-jog-continue operation.
	Feed hold	The machine is in feed hold. Axis motion has stopped, but the spindle continues to turn.
	Feed	The machine is executing a cutting move.
	Rapid	The machine is executing a non-cutting axis move (g00) at the fastest possible rate. Overrides can affect the actual rate.
	Dwell	The machine is executing a dwell (g04) command.
	Singbk stop	Single block mode is active, and the control needs a command to continue.
	Door hold	Machine motion has stopped because of door rules.
	Restricted zone	A current axis position is in the restricted zone.

	Remote jog	The optional remote jog handle is active.
	Vector jog	For five-axis machines, the tool will jog along the vector defined by the rotary positions.
	Low gearbox oil flow	This icon appears when low gearbox oil flow persists for 1 minute.
	Low gearbox oil	The control detected a low gearbox oil level.
	Dirty tsc/hpfc filter	Clean the through-spindle coolant or high-pressure flood coolant filter.
	Low coolant concentrate	Fill the concentrate reservoir for the coolant refill system.
	Low lube	The spindle lubrication oil system detected a low oil condition, or the axis ball screw lubrication system detected a low oil or low-pressure condition.
	Low oil	The rotary brake oil level is low.
	Residual pressure	Before a lubrication cycle the system detected residual pressure from the grease pressure sensor. This can be caused by an obstruction in the axes grease lubrication system.
	Hpu oil low	The hpu oil level is low. The hpu oil level is low. Check the oil level and add the recommended oil for the machine.
	Hpu oil temperature (warning)	The oil temperature is too high to reliably operate the hpu.
	Mist filter	Clean the mist extractor filter.
	Vise clamp	This icon appears when the vise is commanded to clamp.
	Low coolant (warning)	Coolant level is low.


	Mist condenser	This icon appears when the mist condenser is turned on.
	Low air flow	Inch mode - air flow is not sufficient for correct machine operation.
	Low air flow	Metric mode - air flow is not sufficient for correct machine operation.
	Spindle	When you press [handle spindle], the jog handle varies the spindle override percentage.
	Feed	When you press [handle feed], the jog handle varies the feed rate override percentage.
	Handle scroll	When you press [handle scroll], the jog handle scrolls through the text.
	Mirroring	Mirroring mode is active. Either g101 is programmed or setting 45, 46, 47, 48, 80, or 250 (mirror image of axis x, y, z, a, b, c) is set to on.
	Chuck unclamp i.d.	The chuck is unclamped. Note: this icon is used when setting 282, main spindle chuck clamping, is set to i.d.
	Chuck unclamp o.d.	The chuck is unclamped. Note: this icon is used when setting 282, main spindle chuck clamping, is set to o.d.
	C-axis engaged	The c-axis is engaged.
	Spindle fan failed	This icon appears when the spindle fan stops operating.
	Electronics overheat (warning)	This icon appears when the control has detected cabinet temperatures are approaching levels that are potentially dangerous to the electronics. If the temperature reaches or exceeds this recommended level alarm 253 electronics overheat will be generated. Inspect the cabinet for clogged air filters and correctly operating fans.

	Electronics overheat (alarm)	This icon appears when the electronics remains in the overheat state for too long. The machine will not operate until the condition is corrected. Inspect the cabinet for clogged air filters and correctly operating fans.
	Transformer overheat (warning)	This icon appears when the transformer is detected to be overheated for more than 1 second.
	Transformer overheat (alarm)	This icon appears when the transformer remains in the overheat state for too long. The machine will not operate until the condition is corrected.
	Low voltage (warning)	The pdfm detects low incoming voltage. If the condition continues, the machine cannot continue to operate.
	Low voltage (alarm)	The power fault detect module (pdfm) detects incoming voltage that is too low to operate. The machine will not operate until the condition is corrected.
	High voltage (warning)	The pdfm detects incoming voltage above a set limit, but still within operating parameters. Correct the condition to prevent damage to machine components.
	High voltage (alarm)	The pdfm detects incoming voltage that is too high to operate and could cause damage to the machine. The machine will not operate until the condition is corrected.
	Surge protector fault detected	Indicates a surge protector fault has been detected. This icon is active until the fault has been cleared. warning: if continuing to use the machine in this state. The electronics are capable of being damaged due to any electrical surge.
	Robot battery is low	Robot battery is low. Please replace the pulse coder batteries as soon as possible. Do not turn off the robot, otherwise it may require remastering. Reference 9156.062 robot command failed srvo-062 bzal alarm in service documentation for more information.

	Low air (warning)	The air pressure to the machine is too low to reliably operate pneumatic systems. Correct this condition to prevent damage to or incorrect operation of pneumatic systems.
	Low air (alarm)	The air pressure to the machine is too low to operate pneumatic systems. The machine will not operate until the condition is corrected. You may need a higher-capacity air compressor.
	High air (warning)	The air pressure to the machine is too high to reliably operate pneumatic systems. Correct this condition to prevent damage to or incorrect operation of pneumatic systems. You may need to install a regulator at the machine's air input.
	High air (alarm)	The air pressure to the machine is too high to operate pneumatic systems. The machine will not operate until the condition is corrected. You may need to install a regulator at the machine's air input.
	Pendant e-stop	[emergency stop] on the pendant has been pressed. This icon disappears when [emergency stop] is released.
	Auxiliary e-stop	[emergency stop] on an auxiliary device has been pressed. This icon disappears when [emergency stop] is released.
	Remote jog handle-xl (rjh-xl) e-stop	Remote jog handle-xl (rjh-xl) e-stop [emergency stop] on the rjh-xl has been pressed. This icon disappears when [emergency stop] is released.
	Chamfer mode	This icon appears when the e-wheel is in chamfer mode.
	Single blk	Single block mode is active. The control executes programs (1) block at a time. Press [cycle start] to execute the next block.
	Tool life (warning)	The tool life remaining is below setting 240, or the current tool is the last one in its tool group.
	Tool life (alarm)	The tool or tool group has expired, and no replacement tools are available.

	Opt stop	Optional stop is active. The control stops the program at each m01 command.
	Blk delete	Block delete is active. When block delete is on, the control ignores (does not execute) the code following a forward slash (/), on that same line.
	Tool change	A tool change is in progress.
	Probe	The probe system is active.
	Parts catcher	The parts catcher is activated.
	Tailstock hold	The tailstock is engaged with the part.
	Conveyor fwd	The conveyor is active and moving forward.
	Conveyor rev	The conveyor is active and moving in reverse.
	Hpc	The high-pressure coolant system is active.
	Air blast	The auto air gun (aag) is active.
	Hil light	Indicates the optional high intensity (hil) are turned on and the doors are open. Duration is determined by setting 238.
	Coolant	The main coolant system is active.

[illegible]



Keyboard keys are grouped into these functional areas

1	Function
2	Cursor
3	Displays
4	Modes
5	Numeric
6	Alpha Keys
7	Jog Operations
8	Overrides

SPECIAL SYMBOL INPUT

Some special symbols are not on the keypad.

Symbol	Name
_	underscore
^	caret
~	tilde
{	open curly brackets
}	closed curly brackets
\	backslash
	pipe
<	less than
>	greater than

Do these steps to enter special symbols:

1. Press LIST PROGRAMS and select a storage device.
2. Press F3.
3. Select Special Symbols and press ENTER.
4. Enter a number to copy the associated symbol to the INPUT: bar.

For example, to change a directory's name to **MY_DIRECTORY:**

1. Highlight the directory with the name that you want to change.
2. Type MY.
3. Press F3.
4. Select SPECIAL SYMBOLS and press ENTER.
5. Press 1.
6. Type DIRECTORY.
7. Press F3.
8. Select RENAME and press ENTER.

FUNCTION KEYS

List of Function Keys and How They Operate

Name	Key	Function
Reset	[RESET]	Clears alarms. Clears input text. Sets overrides to default values if Setting 88 is ON.
Power up	[POWER UP]	Zero returns all axes and initializes the machine control.
Recover	[RECOVER]	Enters tool changer recovery mode.
F1- F4	[F1 - F4]	These buttons have different functions depending on the tab that is active.
Tool Offset Measure	[TOOL OFFSET MEASURE]	Records tool length offsets during part setup.
Next Tool	[NEXT TOOL]	Selects the next tool from the tool changer.
Tool Release	[TOOL RELEASE]	Releases the tool from the spindle when in MDI, ZERO RETURN, or HAND JOG mode.
Part Zero Set	[PART ZERO SET]	Records work coordinate offsets during part setup.

CURSOR KEY

The cursor keys let you move between data fields, scroll through programs, and navigate through tabbed menus.

Name	Key	Function
Home	[HOME]	Moves the cursor to the top-most item on the screen; in editing, this is the top left block of the program.
Cursor Arrows	Up, Down, Left, Right	Moves one item, block, or field in the associated direction. The keys depict arrows, but this manual refers to these keys by their spelled-out names.
Page Up, Page Down	[PAGE UP] / [PAGE DOWN]	Used to change displays or move up/down one page when viewing a program.
End	[END]	Moves the cursor to the bottom-most item on the screen. In editing, this is the last block of the

DISPLAY KEYS

You use the Display keys to see the machine displays, operational information, and help pages.

Name	Key	Function
Program	[PROGRAM]	Selects the active program pane in most modes.
Position	[POSITION]	Selects the positions display.
Offsets	[OFFSET]	Displays the Tool Offset and Work Offset tabbed menu.
Current Commands	[CURRENT COMMANDS]	Displays menus for Devices, Timers, Macros, Active Codes, Calculators, Advanced Tool Management (ATM), Tool Table, and Media.
Alarms	[ALARMS]	Displays the Alarm viewer and Message screens.
Diagnostics	[DIAGNOSTIC]	Displays tabs for Features, Compensation, Diagnostics, and Maintenance.
Settings	[SETTING]	Displays and allows changing of user settings.
Help	[HELP]	Displays help information.

MODE KEYS

Mode keys change the operational state of the machine. Each mode key is arrow shaped and points to the row of keys that perform functions related to that mode key. The current mode is always displayed in the top left of the screen, in Mode:Key display form.

NOTE: **EDIT** and **LIST PROGRAM** can also act as display keys, where you can access program editors and the device manager without changing the machine mode. For example, while the machine runs a program, you can use the device manager (LIST PROGRAM) or background editor (EDIT) without stopping the program.

Name	Key	Function
EDIT MODE KEYS		
Edit	[EDIT]	Lets you edit programs in the editor. You can access the Visual Programming System (VPS) from the EDIT tabbed menu.
Insert	[INSERT]	Enters text from the input line or the clipboard into the program at the cursor position.
Alter	[ALTER]	Replaces the highlighted command or text with text from the input line or the clipboard. NOTE: ALTER does not work for offsets.
Delete	[DELETE]	Deletes the item that the cursor is on, or deletes a selected program block.
Undo	[UNDO]	Undoes up to the last 40 edit changes, and deselects a highlighted block. NOTE: UNDO does not work for deleted highlighted blocks or to recover a deleted program.

Name	Key	Function
MEMORY MODE KEYS		
Memory	[MEMORY]	Selects memory mode. You run programs in this mode, and the other keys in the MEM row control the ways in which the program is run. Shows OPERATION:MEM in upper left display.
Single Block	[SINGLE BLOCK]	Toggles single block on or off. When single block is on, the control runs only one program block each time you press CYCLE START.
Graphics	[GRAPHICS]	Opens Graphics mode.
Optional Stop	[OPTION STOP]	Toggles optional stop on or off. When optional stop is on, the machine stops when it reaches M01 commands.
Block Delete	[BLOCK DELETE]	Toggles Block Delete On or Off. When Block Delete is On, the control ignores (does not execute) the code following a Forward Slash (/), on that same line.

Name	Key	Function
MDI MODE KEYS		
Manual Data Input	[MDI]	In MDI mode, you run unsaved programs or blocks of code entered from the control. Shows EDIT:MDI in upper left display.
Coolant	[COOLANT]	Turns the optional coolant on and off. Also, SHIFT + COOLANT turns on and off the optional Auto Air Gun / Minimum Quantity Lubrication functions.
Handle Scroll	[HANDLE SCROLL]	Toggles Handle Scroll mode. This lets you use the jog handle to move the cursor in menus while the control is in jog mode.
Automatic Tool Changer Forward	[ATC FWD]	Rotates the tool carousel to the next tool.
Automatic Tool Changer Reverse	[ATC REV]	Rotates the tool carousel to the previous tool.

Name	Key	Function
HANDLE JOG MODE KEYS		
Handle Jog	[HANDLE JOG]	Enters Jog mode.
.0001/.1 .001/1 .01/10 .1/100	[.0001] / [.1], [.001] / [1.], [.01] / [10.], [.1] / [100].]	Selects the increment for each click of the jog handle. When the mill is in MM mode the first number is multiplied by ten when jogging the axis (e.g., .0001 becomes 0.001 mm). The bottom number sets speed after you press JOG LOCK and an axis jog key or you press and hold an axis jog key. Shows SETUP:JOG in the upper left of the display.

Name	Key	Function
ZERO RETURN MODE KEYS		
Zero Return	[ZERO RETURN]	Selects Zero Return mode, which displays axis location in four different categories: Operator, Work G54, Machine, and Dist (distance) To Go. Select the tab to switch between the categories. Shows SETUP: ZERO in the upper-left display.
All	[ALL]	Returns all axes to machine zero. This is like POWER UP, except a tool change does not occur.
Origin	[ORIGIN]	Sets selected values to zero.
Single	[SINGLE]	Returns one axis to machine zero. Press the desired axis letter on the Alpha keyboard and then press SINGLE
Home G28	[HOME G28]	Returns all axes to zero in rapid motion. HOME G28 will also home a single axis in the same manner as SINGLE.
CAUTION: Make sure the axis motion paths are clear when you press this key. There is no warning or prompt before axis motion begins.		
LIST PROGRAM MODE KEYS		
List Programs	[LIST PROGRAM]	Accesses a tabbed menu to load and save programs.
Select Programs	[SELECT PROGRAM]	Makes the highlighted program the active program.
Back	[BACK ARROW]	Navigates to the screen you were on before the current one. This key operates like the BACK button on a web browser.
Forward	[FORWARD ARROW]	Navigates to the screen you went to after the current screen, if you have used the back arrow. This key operates like the FORWARD button on a web browser.
Erase Program	[ERASE PROGRAM]	Deletes the selected program in List Program mode. Deletes the entire program in MDI mode.

NUMERIC KEYS

Use the numeric keys to type numbers, along with some special characters (printed in yellow on the main key). Press SHIFT to enter the special characters.

Name	Key	Function
Numbers	0-9	Types numbers.
Minus sign	-	Adds a minus (-) sign to the input line.
Decimal point	.	Adds a decimal point to the input line.
Cancel	[CANCEL]	Deletes the last character typed.
Space	[SPACE]	Adds a space to input.
Enter	[ENTER]	Answers prompts and writes input.
Special Characters	Press [SHIFT], then a numeric key	Inserts the yellow character on the upper-left of the key. These characters are used for comments, macros, and certain special features.
+	[SHIFT], then -	Inserts +
=	[SHIFT], then 0	Inserts =
#	[SHIFT], then .	Inserts #
*	[SHIFT], then 1	Inserts *
'	[SHIFT], then 2	Inserts '
?	[SHIFT], then 3	Inserts ?
%	[SHIFT], then 4	Inserts %
\$	[SHIFT], then 5	Inserts \$
!	[SHIFT], then 6	Inserts !
&	[SHIFT], then 7	Inserts &
@	[SHIFT], then 8	Inserts @
:	[SHIFT], then 9	Inserts :

ALPHA KEYS

Use the alpha keys to type the letters of the alphabet, along with some special characters (printed in yellow on the main key). Press SHIFT to enter the special characters.

Name	Key	Function
Alphabet	[A-Z]	Uppercase letters are the default. Press SHIFT and a letter key for lowercase.
End-of-block (EOB)	;	This is the end-of-block character, which signifies the end of a program line.
Parentheses	(,)	Separate CNC program commands from user comments. They must always be entered as a pair.
Shift	[SHIFT]	Accesses additional characters on the keyboard or shifts to lower case alpha characters. The additional characters are seen in the upper left of some of the alpha and number keys.
Special Characters	Press [SHIFT], then an alpha key	Inserts the yellow character on the upper-left of the key. These characters are used for comments, macros, and certain special features.
Forward Slash	[SHIFT], then ;	Inserts /
Left Bracket	[SHIFT], then (Inserts [
Right Bracket	[SHIFT], then)	Inserts]

Name	Key	Function
Tailstock towards spindle	[TS ←]	Press and hold this key to move the tailstock towards the spindle.
Tailstock rapid	[TS RAPID]	Increases the speed of the tailstock when pressed simultaneously with one of the other tailstock keys.
Tailstock away from spindle	[TS →]	Starts the chip removal system in the "reverse" direction.
Axis Jog Keys	+X/-X, +Y/-Y, +Z/-Z, +A/C/-A/C and +B/-B ([SHIFT] +A/C/-A/C)	Jog axes manually. Press and hold the axis button, or press and release to select an axis and then use the jog handle.
Jog Lock	[JOG LOCK]	Works with the axis jog keys. Press JOG LOCK, then an axis button, and the axis moves until you press JOG LOCK again.
Coolant Up	[CLNT UP]	Moves the optional Programmable Coolant (P-Cool) nozzle up.
Coolant Down	[CLNT DOWN]	Moves the optional P-Cool nozzle down.
Auxiliary Coolant	[AUX CLNT]	Press this key in MDI mode to toggle the Through-Spindle Coolant (TSC) system operation, if equipped. Press SHIFT + AUX CLNT to toggle the Through Tool Air Blast (TAB) function, if equipped. Both functions also work in Run-Stop-Jog-Continue mode.

OVERRIDE KEYS

Overrides let you temporarily adjust the speeds and feeds in your program. For example, you can slow down rapids while you prove out a program, or adjust the feedrate to experiment with its effect on part finish, etc.

You can use Settings 19, 20, and 21 to disable the feedrate, spindle, and rapid overrides, respectively.

FEED HOLD acts as an override that stops rapid, and feed moves when you press it. **FEED HOLD** also stops tool changes and part timers, but not tapping cycles or dwell timers.

Press **CYCLE START** to continue after a **FEED HOLD**. When the Setup Mode key is unlocked, the door switch on the enclosure also has a similar result but displays Door Hold when the door is opened. When the door is closed, the control is in Feed Hold and CYCLE START must be pressed to continue. Door Hold and **FEED HOLD** do not stop any auxiliary axes.

You can override the standard coolant setting by pressing **COOLANT**. The coolant pump remains either on or off until the next M-code or operator action (see Setting 32).


Use Settings **83**, **87**, and **88** to have **M30** and **M06** commands, or **RESET**, respectively, change overridden values back to their defaults.

Name	Key	Function
-10% Feedrate	[-10% FEEDRATE]	Decreases the current feedrate by 10%.
100% Feedrate	[100% FEEDRATE]	Sets an overridden feedrate back to the programmed feed rate.
+10% Feedrate	[+10% FEEDRATE]	Increases the current feedrate by 10%.
Handle Control Feed Rate	[HANDLE FEED]	Lets you use the jog handle to adjust the feedrate in 1% increments.
-10% Spindle	[-10% SPINDLE]	Decreases the current spindle speed by 10%
100% Spindle	[100% SPINDLE]	Sets the overridden spindle speed back to the programmed speed.
+10% Spindle	[+10% SPINDLE]	Increases the current spindle speed by 10%.
Handle Spindle	[HANDLE SPINDLE]	Lets you use the jog handle to adjust the spindle speed in 1% increments.
Forward	[FWD]	Starts the spindle in the clockwise direction.
Stop	[STOP]	Stops the spindle.
Reverse	[REV]	Starts the spindle in the counterclockwise direction.
Rapids	[5% RAPID]/ [25% RAPID]/ [50% RAPID] / [100% RAPID]	Limits machine rapids to the value on the key.

CONTROL DISPLAY

The control display is organized into panes that change with the different machine and display modes.

Basic Control Display Layout in Operation: Mem Mode (While a Program Runs)



1	Mode, Network, and Time Status Bar
2	Program Display
3	Main Display (size varies)/ Program/ Offsets/Current Commands/ Settings/ Graphics/ Editor/ VPS/ Help
4	Active Codes
5	Active Tool
6	Coolant
7	Timers, Counters / Tool Management
8	Alarm Status
9	System Status Bar
10	Position Display / Axis Load
11	Input Bar
12	Icon Bar
13	Spindle Status

The active pane has a white background. You can work with data in a pane only when that pane is active, and only one pane is active at a time. For example, when you select the Tool Offsets tab, the offsets table background turns white. You can then make changes to the data. In most cases, you change the active pane with the display keys.

TABBED MENU BASIC NAVIGATION

The Haas control uses tabbed menus for several modes and displays. Tabbed menus keep related data together in an easy-to-access format. To navigate these menus:

1. Press a display or mode key.

The first time you access a tabbed menu, the first tab (or sub-tab) is active. The highlight cursor is at the first available option in the tab.

2. Use the cursor keys or the HANDLE JOG control to move the highlight cursor within an active tab.
3. To choose a different tab in the same tabbed menu, press the mode or display key again.
NOTE: If the cursor is at the top of the menu screen, you can also press the UP cursor arrow key to select a different tab.

The current tab becomes inactive.

4. Use the cursor keys to highlight a tab or a sub-tab, and press the DOWN cursor arrow key to use the tab.

NOTE: You cannot make the tabs active in the POSITIONS tabbed display.

5. Press a different display or mode key to work with a different tabbed menu.


INPUT BAR

The input bar is the data entry section located in the bottom-left corner of the screen. This is where your input appears as you type it.

Mode, Network, and Time Status Bar

This status bar in the top left of the screen is divided into three sections: mode, network, and time.

The Mode, Network, and Time Status bar shows [1] the current machine mode, [2] network status icons, and [3] the current time.











Mode [1]

The Haas control organizes machine functions into three modes: Setup, Edit, and Operation. Each mode shows on one screen all of the information you need to do tasks under that mode. For example, in Setup mode, you have access to the work offset table, the tool offset table, and position information. Edit mode gives you access to the program editor and optional systems like Visual Programming (VPS) (which contains Wireless Intuitive Probing (WIPS)). Operation mode includes Memory (MEM), the mode in which you run programs.

Mode	Keys	Display [1]	Function
Setup	ZERO RETURN	SETUP: ZERO	Provides all control features for machine setup.
	HANDLE JOG	SETUP: JOG	
Edit	EDIT	ANY	Provides all program editing, management, and transfer functions.
	MDI	EDIT: MDI	
	LIST PROGRAM	ANY	
Operation	MEMORY	OPERATION: MEM	Provides all control features necessary to run a program.
	EDIT	OPERATION: MEM	Provides background editing of active programs.
	LIST PROGRAM	ANY	Provides background editing of programs.

If you have networking installed on your Next Generation Control, icons in the center networking partition of the bar give you networking status. See the table for meanings of the networking icons.

ICON	Network Status
	The machine is connected to a wired network with an Ethernet cable.
	The machine is connected to a wireless network with 70 - 100% signal strength.
	The machine is connected to a wireless network with 30 - 70% signal strength.
	The machine is connected to a wireless network with 1 - 30% signal strength.
	The machine is connected to a wireless network, but it is not receiving data packets.
	The machine is successfully registered with MyHaas and is communicating with the server.
	The machine had previously registered with MyHaas and has a problem connecting to the server.
	The machine is connected to a remote net share.

SETTINGS DISPLAY

Press **SETTING**, then select the **SETTINGS** tab. Settings change the way the machine behaves; refer to the “Settings” section for a more detailed description.

COOLANT DISPLAY

The coolant display appears in the upper-right of the screen in **OPERATION:MEM** mode.

The first line tells you if the coolant is **ON** or **OFF**.

The next line shows the position number of the optional Programmable Coolant Spigot (**P-COOL**). The positions are from 1 to 34. If the option is not installed, no position number appears.

In the coolant gauge, a black arrow shows the coolant level. Full is 1/1 and empty is 0/1. To avoid coolant flow problems, keep the coolant level above the red range. You can also see this gauge in **DIAGNOSTICS** mode under the **GAUGES** tab.

OFFSET DISPLAY

To access the offset tables, press **OFFSET** and select the **TOOL** tab or the **WORK** tab.

Name	Function
TOOL	Display and work with tool numbers and tool length geometry.
WORK	Display and work with part zero locations.

POSITION DISPLAY

The Position display shows the current axis position relative to four reference points (Work, Distance-to-go, Machine, and Operator). In any mode, press **POSITION** and use cursor keys to access the different reference points displayed in tabs. The last tab display shows all the reference points on the same screen.


Coordinate Display	Function
WORK (G54)	This tab displays the axis positions relative to part zero. On power-up, this position uses work offset G54 automatically. It displays the axis positions relative to the most recently used work offset.
DIST TO GO	This tab displays the distance remaining before the axes reach their commanded position. When in SETUP: JOG mode, you can use this position display to show a distance moved. Change modes (MEM , MDI) and then switch back to SETUP: JOG mode to zero this value.
MACHINE	This tab displays the axis positions relative to machine zero.
OPERATOR	This tab shows the distance you have jogged the axes. This does not necessarily represent the actual distance the axis is from machine zero, except when the machine is first powered on.
ALL	This tab displays all reference points on the same screen.

AXIS DISPLAY SELECTION

You can add or remove axes in the Positions displays. While the Positions display tab is active, press **ALTER**. The axis display selection window comes in from the right side of the screen.

Use the cursor arrow keys to highlight an axis, and press ENTER to toggle it on and off for display. The positions display will show axes that have a check mark. Press ALTER to close the axis display selector.

NOTE: You can display a maximum of (5) axes.



CURRENT COMMANDS

This section describes the Current Commands pages and the types of data they show. The information from most of these pages also appears in other modes.

Press **CURRENT COMMANDS** to access the tabbed menu of available Current Commands displays.

Devices -The Mechanisms tab on this page shows hardware devices on the machine that you can command manually. For example, you can manually extend and retract the Parts Catcher or Probe Arm. You can also manually rotate the spindle clockwise or counterclockwise at a desired RPM.

Timers Display -This page shows:

- The current date and time.
- The total power on time.
- Total cycle start time.
- Total feed time.
- M30 counters. Each time the a program reaches an M30 command, both of these counters increment by one.
- Macro variable displays.

You also see these timers and counters in the lower-right section of the display in the OPERATION:MEM, SETUP:ZERO, and EDIT:MDI modes.

Macros Display -This page shows a list of the macro variables and their values. The control updates these variables as programs run. You can modify the variables in this display.

Active Codes -This page lists the active program codes. A smaller version of this display is included on the OPERATION:MEM and EDIT:MDI mode screens. Also when you press PROGRAM in any Operation mode, you see the active program codes.

Advanced Tool Management -This page contains information the control uses to predict tool life. Here is where you create and manage tool groups, and where you enter the maximum tool load percentage expected for each tool. For more information, refer to the **Advanced Tool Management** section in the Operation chapter of this manual.

Calculator -This page contains the Standard, Milling/Turning, and Tapping calculators.

Media -This page contains the Media Player.


DEVICES – MECHANISMS

The Mechanisms page displays possible machine components and options on your machine. Select the listed mechanism using the UP and DOWN arrows for more information on its operation and use. Pages give detailed instructions on the functions of the machine components, quick tips, as well as links to other pages to help you learn about and utilize your machine.

- Select the Devices tab in the Current Commands menu.
- Select the Mechanisms that you want to use.

The Main Spindle option in Devices allows you to rotate the spindle clockwise or counterclockwise at a chosen RPM. The maximum RPM is limited by the machine's maximum RPM settings.

- Use the cursor arrow keys to move from field to field.
- Enter the RPM you want to rotate the spindle and press **[F2]**.
- Hold down **[F3]** to rotate the spindle clockwise. Hold down **[F4]** to rotate the spindle counterclockwise. The spindle comes to a stop when the button is released.



The Parts Catcher option in Devices allows you to Extend and Retract the parts catcher. The door must be fully closed.

- Use the cursor arrow keys to move from field to field.
- Press **[F2]** to extend the parts catcher and press **[F2]** to retract the parts catcher.
- Press **[F3]** to partially extend the parts catcher to the part-off position.
- To setup the dual action parts catcher refer to: See Dual Action - Parts Catcher - Setup for more information.

Current Commands

Devices

Timers

Macro Vars

Active Codes

ATM

Calculator

Media

Mechanisms

Device	State
Main Spindle	Off
Parts Catcher	Retracted
Probe Arm	Retracted

Main Spindle

Number + **F2** Set RPM

Hold **F3** **to rotate clockwise

Hold **F4** **to rotate counterclockwise

**Use [F2] to set the speed to rotate at, a value of zero will turn this feature off.

**Press and hold [F3] to rotate clockwise and [F4] to rotate counterclockwise

**Once the button is released the spindle will come to a stop

The Probe Arm option in Devices allows you to Extend and Retract the probe arm. The door must be fully opened or fully closed.



- Use the cursor arrow keys to move from field to field.
- Press **[F2]** to extend the probe arm and press **[F2]** to retract the probe arm.

The Main Spindle Chuck Pressure option in Devices allows you to program the chuck pressure.

- Use the cursor arrow keys to move from field to field.
- Enter the desired chuck pressure and press **[F2]** to set the pressure.

Notes:

- The value entered must be an integer (whole number).
- Increasing the pressure will increase the gripping force immediately.
- Decreasing the pressure will not affect gripping force if the chuck is already clamped. The chuck must be stopped, unclamped and clamped again.
- The maximum pressure depends on the chuck size.



The Bar Feeder tab on Devices allows you to set up the Bar feeder system variables.

- Use the cursor arrow keys to move from field to field.

Current Commands

Devices
Timers
Macro Vars
Active Codes
ATM
Calculator
Media

Mechanisms
Bar Feeder



F2 Load and Measure Bar

F3 Advance Bar

F4 Set Collet Face Position

INSERT Set Push Rod Offset

Bar Feeder System Variables

Description	Value	Unit
Length of Longest Bar	48.0000	IN
Total Push Length (D)	0.0000	IN
Total Initial Push Length (F)	0.0000	IN
Minimum Clamping Length (G)	0.0000	IN
Maximum Number of Parts	0	
Maximum Number of Bars	0	
Set up 1: Load Bar and Measure	--	
Set up 2: Adjust Transfer Tray Height	--	

TIME ADJUSTMENT

Follow this procedure to adjust the date or time.

1. Select the Timers page in Current Commands.
2. Use the cursor arrow keys to highlight the Date:, Time:, or Time Zone field.
3. Press **[EMERGENCY STOP]**.
4. In the Date: field, type the new date in the format **MM-DD-YYYY**, including the hyphens.
5. In the Time: field, type the new time in the format **HH:MM**, including the colon.
Press **[SHIFT]** and then 9 to type the colon.
6. In the Time Zone: field, press **[ENTER]** to select from the list of time zones. You can type search terms in the pop-up window to narrow the list. For example, type PST to find Pacific Standard Time. Highlight the time zone you want to use.
7. Press **[ENTER]**.

Timer and Counter Reset

You can reset the power-on, cycle-start, and feed cutting timers. You can also reset the M30 counters.

1. Select the Timers page in Current Commands.
2. Use the cursor arrow keys to highlight the name of the timer or counter that you want to reset.
3. Press ORIGIN to reset the timer or counter.

tip: You can reset the M30 counters independently to track finished parts in two different ways; for example, parts finished in a shift and total parts finished.

CURRENT COMMANDS - ACTIVE CODES

This display gives read-only, real-time information about the codes that are currently active in the program; specifically,

- the codes that define the current motion type (rapid vs linear feed vs circular feed)
- positioning system (absolute vs incremental)
- cutter compensation (left, right or off)
- active canned cycle, and work offset.

This display also gives the active Dnn, Hnn, Tnn, and most recent M-code. If an alarm is active, this shows a quick display of the active alarm instead of the active codes.


Current Commands						
Devices	Timers	Macro Vars	Active Codes	Tools	Plane	Calculator
G-Codes		Address Codes	DHMT Codes	Speeds & Feeds		
G00	N	0	D 00	Programmed Feed Rate	0.	IPM
G17	X	0.	H 00	Actual Feed Rate	0.	IPM
G90	Y	0.	M 00	G50 Max Spindle RPM	0	RPM
G94	Z	0.	T 00	Main Spindle		
G20	I	0.		Programmed Speed	0	RPM
G40	J	0.		Commanded Speed	0	RPM
G43	K	0.		Actual Speed	0	RPM
G80	P	0		Direction	Stop	
G98	Q	0.				
G50	R	0.				
G54	O	000000				
G269	A	0.				
G64	B	0.				
G69	C	0.				
G170	U	0.				
G255	V	0.				
	W	0.				
	E	0.				

ENTER View full text.

TOOLS - TOOL USAGE

The Tool Usage tab contains information about the tools used in a program. This display will tell you information about each tool used in a program and statistics about each time it was used. It starts to collect information when user Main program start and clear information when meet codes M99, M299, M199.

To get to the Tool Usage display press CURRENT COMMANDS then go to Tools and then Tool Usage tab.



Start Time - When the tool was inserted to the spindle.

Total Time - The total time the tool has been in the spindle.

Feed time - Tool usage time.

Load% - The maximum load of the Spindle during a tool usage.

NOTE: This value is retrieved every second. The actual load compared to the recorded may vary.

Feed/Total time - A graphic representation of the feed time of the tool over the total time.

Engagement:

- Black Bar- The tool usage versus another tools.
- Gray Bar - This bar shows how long the tool was used in this usage related to other usages.

MACROS INTERFACE

You can use these macros variables to set and collect the tool usage data.

Macro Variable	Function
#8608	Set the desired tool
#8609	Current tool number - if result more 0 (the tool was used)
#8610	Total time mentioned in #8609 tool number
#8611	Feed time of mentioned tool number
#8612	Total time
#8605	Next usage of a tool
#8614	Usage start time stamp
#8615	Usage Total time
#8616	Usage Feed time
#8617	Usage Max load

ADVANCED TOOL MANAGEMENT

Advanced Tool

Management (ATM) lets you set up groups of duplicate tools for the same or a series of jobs.

ATM classifies duplicate or backup tools into specific groups. In your program, you specify a group of tools instead of a single tool. ATM tracks the tool use in each tool group and compares it to your defined limits. When a tool reaches a limit, the control considers it “expired.” The next time your program calls that tool group, the control chooses a non-expired tool from the group.

Current Commands

Devices Timers Macro Vars Active Codes Tools Plane Calculator

Tool Table Tool Usage **ATM**

F4 To Switch Boxes Allowed Limits Active Tool: 0

Group	Expired Count	Tool Order	Holes Limit	Usage Limit	Life Warn %	Expired Action	Feed
All	-	-	-	-	-	-	-
Expired	0	-	-	-	-	-	-
No Group	-	-	-	-	-	-	-
Add Group	-	-	-	-	-	-	-

Tool Data For Group: All

Tool	Pocket	Life	Holes Count	Usage Count	Usage Limit	H-Code	D
1		100%	0	0	0	0	0
2		100%	0	0	0	0	0
3		100%	0	0	0	0	0
4		100%	0	0	0	0	0

INSERT Add Group

When a tool expires:

- The beacon will flash.
- ATM puts the expired tool in the EXP group
- Tool groups that contain the tool appear with a red background.

To use ATM, press CURRENT COMMANDS, and then select ATM in the tabbed menu. The ATM window has two sections: Allowed Limits and Tool Data.

ALLOWED LIMITS

This table gives data about all of the current tool groups, including default groups and user-specified groups. ALL is a default group that lists all of the tools in the system. EXP is a default group that lists all of the tools that are expired. The last row in the table shows all of the tools that are not assigned to tool groups. Use the cursor arrow keys or END to move the cursor to the row and see these tools.

For each tool group in the ALLOWED LIMITS table, you define limits that determine when a tool expires. The limits apply to all tools assigned to this group. These limits affect every tool in the group.

The columns in the ALLOWED LIMITS table are:

- **GROUP** - Displays the tool group's ID number. this is the number you use to specify the tool group in a program.
- **EXPIRED COUNT** - Tells you how many tools in the group are expired. If you highlight the ALL row, you see a list of all of the expired tools in all groups.
- **TOOL ORDER** - Specifies the tool to use first. If you select ORDERED, ATM uses the tools in tool number order. You can also have ATM automatically use the NEWEST or OLDEST tool in the group.
- **HOLES LIMIT** - The maximum number of holes a tool is allowed to drill before it expires.
- **USAGE LIMIT** - The maximum number of times the control can use a tool before it expires.
- **LIFE WARN %** - The minimum value for tool life remaining in the group before the control gives a warning message.
- **EXPIRED ACTION** - The automatic action when a tool reaches its maximum tool load percentage. Highlight the tool action box to change and press ENTER. Use the UP and DOWN cursor keys to select the automatic action from the pull down menu (ALARM, FEEDHOLD, BEEP, AUTOFEED, NEXT TOOL).
- **FEED LIMIT** - The total amount of time, in minutes, that the tool can be in a feed.
- **TOTAL TIME LIMIT** - The total amount of time, in minutes, that the control can use a tool.
- **MAIN SPINDLE LOAD LIMIT** - The allowed load limit for tools in the group before the control issues a warning.
- **SUB SPINDLE LOAD LIMIT** - The allowed load limit for tools in the group before the control issues a warning.
- **LIVE TOOL LOAD LIMIT** - The allowed load limit for tools in the group before the control issues a warning.

TOOL DATA

This table gives information about each tool in a tool group. To look at a group, highlight it in the ALLOWED LIMITS table, and then press F4.

- **TOOL** - Shows the tool numbers used in the group.
- **POCKET** - Shows the pocket numbers used in the group.
- **LIFE** - The percentage of life left in a tool. This is calculated by the CNC control, using actual tool data and the allowed limits the operator entered for the group.
- **HOLES COUNT** - The number of holes the tool has drilled/ tapped/ bored.
- **USAGE COUNT** - The total number of times that a program has called the tool (number of tool changes).
- **USAGE LIMIT** - The total number of times that a tool can be used (number of tool changes).
- **FEED TIME** - The amount of time, in minutes, the tool has been in a feed.
- **TOTAL TIME** - The total amount of time, in minutes, the tool has been used.
- **MAIN SPINDLE MAX LOAD** - The maximum load, in percent, exerted on the tool.
- **MAIN SPINDLE LOAD LIMIT** - The maximum load allowed for the tool before warning issued.
- **SUB SPINDLE MAX LOAD** - The maximum load, in percent, exerted on the tool.
- **SUB SPINDLE LOAD LIMIT** - The maximum load allowed for the tool before warning issued.
- **LIVE TOOL MAX LOAD** - The maximum load, in percent, exerted on the tool.
- **LIVE TOOL LOAD LIMIT** - The maximum load allowed for the tool before warning issued.


PLANE

The **Plane** tab allows for a machine with a Gimbal Spindle define custom planes for jogging.

The plane tab can used in conjunction with G268 run in a program or from filling out the required fields.

Each one of the required fields has a help text at the bottom of the table.

To enter plane jogging mode type in "**PJ**" followed by **[HAND JOG]**.



Name	Value	Units
I Code	0.000	Deg
J Code	0.000	Deg
K Code	0.000	Deg
Q Code	>	Q123

Plane Jogging Is Off. To turn on, press "PJ" followed by the Handjog key.


CALCULATOR

The calculator tab includes calculators for basic mathematical functions, milling, and tapping.

- Select the calculator tab in the Current Commands menu.
- Select the calculator tab that you want to use: Standard, Milling, or Tapping.

The standard calculator has functions like a simple desktop calculator; with available operations such as addition, subtraction, multiplication, and division, as well as square root and percentage. The calculator lets you easily transfer operations and results to the input line so that you can put them into programs. You can also transfer results into the Milling and Tapping calculators.

Use the number keys to type operands into the calculator.



7	8	9	+ [D]	+/- [E]	MS [S]
4	5	6	- [J]	sqrt [K]	MR [R]
1	2	3	* [P]	% [Q]	MC [C]
(0)	/ [V]	Enter	
Clear [ORIGIN]			.		

To insert an arithmetic operator, use the letter key that appears in brackets next to the operator you want to insert.

These keys are:

KEY	FUNCTION	KEY	FUNCTION
D	Add	K	Square Root
J	Subtract	Q	Percentage
P	Multiply	S	Memory Store (MS)
V	Divide	R	Memory Recall (MR)
E	Toggle sign (+/-)	C	Memory Clear (MC)

After you have entered data into the calculator input field, you can do any of the following:

NOTE: These options are available for all calculators.

- Press ENTER to return the result of your calculation.
- Press INSERT to append the data or the result to the end of the input line.
- Press ALTER to move the data or the result to the input line. This overwrites the current contents of the input line.
- Press ORIGIN to reset the calculator.

Keep the data or the result in the calculator input field and select a different calculator tab. The data in the calculator input field remains available to transfer into the other calculators.

MILLING /TURNING CALCULATOR

The milling/turning calculator lets you automatically calculate machining parameters based on given information. When you have entered enough information, the calculator automatically displays results in the relevant fields. These fields are marked with an asterisk (*).

- Use the cursor arrow keys to move from field to field.
- Type known values in the appropriate fields. You can also press F3 to copy a value from the standard calculator.
- In the Work Material and Tool Material fields, use the LEFT and RIGHT cursor arrow keys to choose from the available options.
- Calculated values appear highlighted in yellow when they are outside of the recommended range for the workpiece and tool material. Also, when all of the calculator fields contain data (calculated or entered), the milling calculator displays the recommended power for the operation.

Current Commands

Devices Timers Macro Vars Active Codes Tools Plane Calculator

Standard **Milling** Tapping

Cutter Diameter ***** in

Surface Speed ***** ft/min

RPM *****

Flutes *****

Feed ***** in/min

Chip Load ***** in/tth

Work Material ◀ No Material Selected ▶

Tool Material ◀ Please Select Work Material ▶

Cut Width ***** in

Cut Depth ***** in

F2 Switch Entry To Input Line

INSERT To append to INPUT line.

ALTER To replace INPUT line.

ORIGIN Clear current input

F3 Copy Value From Standard Calculator

F4 Paste Current Value To Standard Calculator

* Next to Field Name Denotes Calculated Value

TAPPING CALCULATOR

The tapping calculator lets you automatically calculate tapping parameters based on given information. When you have entered enough information, the calculator automatically displays results in the relevant fields. These fields are marked with an asterisk (*).

- Use the cursor arrow keys to move from field to field.
- Type known values in the appropriate fields. You can also press F3 to copy a value from the standard calculator.
- When the calculator has enough information, it puts calculated values in the appropriate fields.

The screenshot shows a software window titled 'Current Commands' with a star icon in the top right. Below the title bar is a menu bar with 'Devices', 'Timers', 'Macro Vars', 'Active Codes', 'Tools', 'Plane', and 'Calculator'. The 'Calculator' menu is open, showing sub-menus: 'Standard', 'Milling', and 'Tapping' (which is highlighted in orange). The main area of the window is divided into two columns. The left column contains four input fields: 'TPI' with a unit of 'rev/in', 'Metric Lead' with a unit of 'mm/rev', 'RPM', and 'Feed' with a unit of 'in/min'. Each field has a placeholder text '****, ****'. The right column contains four function buttons: 'F2' (Switch Entry To Input Line), 'INSERT' (To append to INPUT line.), 'ALTER' (To replace INPUT line.), and 'ORIGIN' (Clear current input). Below these buttons are three more function buttons: 'F3' (Copy Value From Standard Calculator), 'F4' (Paste Current Value To Standard Calculator), and another 'F4' (Paste Current Value To Standard Calculator). At the bottom left of the window, there is a note: '* Next to Field Name Denotes Calculated Value'.

MEDIA DISPLAY

M130 Lets you display video with audio and still images during program execution. Some examples of how you can use this feature are:

Providing visual cues or work instructions during program operation

Providing images to aid part inspection at certain points in a program

Demonstrating procedures with video

The correct command format is M130(file.xxx), where file.xxx is the name of the file, plus the path, if necessary. You can also add a second comment in parentheses to appear as a comment in the media window.

Example: M130(Remove Lifing Bolts Before Starting Op 2)(User Data/My Media/loadOp2.png);

note: M130 uses the subprogram search settings, Settings 251 and 252 in the same way that M98 does. You can also use the Insert Media File command in the editor to easily insert an M130 code that includes the file path.

\$FILE Lets you display video with audio and still images outside of program execution.

The correct command format is (\$FILE file.xxx), where file.xxx is the name of the file, plus the path, if necessary. You can also add a comment between the first parentheses and the dollar sign to appear as a comment in the media window.

To display the media file, highlight the block while in memory mode and press enter. \$FILE media display block will be ignored as comments during program execution.

Example: (Remove Lifting Bolts Before Starting Op 2 \$FILE User Data/My Media/loadOp2.png);

Standard	Profile	Resolution	Bitrate
MPEG-2	Main-High	1080 i/p, 30 fps	50 Mbps
MPEG-4 / XviD	SP/ASP	1080 i/p, 30 fps	40 Mbps
H.263	P0/P3	16 CIF, 30fps	50 Mbps
DivX	3/4/5/6	1080 i/p, 30fps	40 Mbps
Baseline	8192 x 8192	120 Mpixel/sec	-
PNG	-	-	-
JPEG	-	-	-

NOTE: For the fastest loading times, use files with pixel dimensions divisible by 8 (most unedited digital images have these dimensions by default), and a maximum resolution of 1920 x 1080.

Your media appears in the Media tab under Current Commands. The media displays until the next M130 displays a different file, or M131 clears the media tab contents.

ALARMS AND MESSAGES DISPLAY

Use this display to learn more about machine alarms when they occur, view your machine's entire alarm history, look up definitions of alarms that can occur, view created messages, and show the keystroke history.

Press ALARMS, then select a display tab:

The ACTIVE ALARM tab shows the alarms that currently affect machine operation. Use PAGE UP and PAGE DOWN to see the other active alarms.

The MESSAGES tab shows the messages page. The text you put on this page stays there when you power the machine off. You can use this to leave messages and information for the next machine operator, etc.

The ALARM HISTORY tab shows a list of the alarms that have recently affected machine operation. You can also search for an alarm number or alarm text. To do this type in the alarm number or the desired text and press F1.

The ALARM VIEWER tab shows a detailed description of all the alarms. You can also search for an alarm number or alarm text. To do this type in the alarm number or the desired text and press F1.

The KEY HISTORY tab shows up to the last 2000 keystrokes.

ADD MESSAGES

You can save a message in the MESSAGES tab. Your message stays there until you remove it or change it, even when you turn the machine off.


1. Press ALARMS, select the MESSAGES tab, and press the DOWN cursor arrow key.
2. Type your message.
Press CANCEL to backspace and delete. Press DELETE to delete an entire line. Press ERASE PROGRAM to delete the entire message.

MAINTENANCE

Thermal Compensation tab under Maintenance in Diagnostics that was released in software version **100.21.000.1130**.

This tab has two options to switch between, a simple gauge version and a more detailed view.


Note: For now, this tab is purely for informational purposes.



LOAD CALIBRATION

The Load Calibration tab allows the user to calibrate the spindle performance across different chuck and part sizes. The choices are:

- Default - Recommended when using a standard size chuck and part.
- Calibrated - Recommended when using a large or small size chuck or collet and a large or small part.



See [Setting 413 Main Spindle Load Type](#) for more information.

DEVICE MANAGER (LIST PROGRAM)

You use the device manager (LIST PROGRAM) to access, save, and manage data on the CNC control, and on other devices attached to the control. You also use the device manager to load and transfer programs between devices, set your active program, and back up your machine data.

In the tabbed menu at the top of the display, the device manager (LIST PROGRAM) shows you only the available memory devices. For example, if you do not have a USB memory device connected to the control pendant, the tabbed menu does not show a USB tab. For more information on navigating tabbed menus, refer to Chapter 5.1.

The device manager (LIST PROGRAM) shows you the available data in a directory structure. At the root of the CNC control are the available memory devices in a tabbed menu. Each device can contain combinations of directories and files, many levels deep. This is like the file structure you find in common personal computer operating systems.

DEVICE MANAGER OPERATION

Press LIST PROGRAM to access the device manager. The initial device manager display shows the available memory devices in a tabbed menu. These devices can include machine memory, the User Data directory, USB memory devices connected to the control, and files available on the connected network. Select a device tab to work with the files on that device.


Device Manager Initial Screen

Example:

- [1] Available Device Tabs,
- [2] Search Box,
- [3] Function Keys,
- [4] File Display,
- [5] File Comments (only available in Memory).

Use the cursor arrow keys to navigate the directory structure:

Use the UP and DOWN cursor arrow keys to highlight and interact with a file or a directory in the current root or directory.



Roots and directories have a right-hand arrow character (>) in the far-right column of the file display. Use the RIGHT cursor arrow key to open a highlighted root or directory. The display then shows the contents of that root or directory. Use the LEFT cursor arrow key to return to the previous root or directory. The display then shows the contents of that root or directory.

The CURRENT DIRECTORY message above the file display tells you where you are in the directory structure; for example: MEMORY/CUSTOMER 11/NEW PROGRAMS shows that you are in the subdirectory NEW_PROGRAMS inside the directory CUSTOMER 11, in the root of MEMORY.

FILE DISPLAY COLUMNS

When you open a root or directory with the RIGHT cursor arrow key, the file display shows you a list of the files and directories in that directory. Each column in the file display has information about the files or directories in the list

The columns are:

File selection check box (no label): Press ENTER to toggle a check mark on and off in the box. A check mark in a box indicates that the file or directory selected for operations on multiple files (usually copy or delete).

Program O Number (O #): This column lists the program numbers of the programs in the directory. The letter 'O' is omitted in the column data. Only available in the Memory tab.

File comment (Comment): This column lists the optional program comment that appears in the first line of the program. Only available in the Memory tab.

File Name (File Name): This is an optional name that the control uses when you copy the file to a memory device other than the control. For example, if you copy program O00045 to a USB memory device, the filename in the USB directory is NEXTGENTest.nc.

File Size (Size): This column shows the amount of storage space that the file takes up. Directories in the list have the designation <DIR> in this column.

NOTE: This column is hidden by default, press the F3 button and select Show File Details to display this column.

Date Last Modified (Last Modified): This column shows the last date and time when the file was changed. The format is YYYY/MM/DD HR:MIN.

NOTE: This column is hidden by default, press the F3 button and select Show File Details to display this column.

Other Information (no label): This column gives you some information about a file's status. The active program has an asterisk (*) in this column. A letter E in this column means that the program is in the program editor. A greater-than symbol (>) indicates a directory. A letter S indicates that a directory is part of Setting 252. Use the RIGHT or LEFT cursor arrow keys to enter or exit the directory.

Current Directory: Memory/						
	O #	Comment	File Name	Size	Last Modified	
<input type="checkbox"/>			TEST	<DIR>	2015/11/23 08:54	>
<input type="checkbox"/>			programs	<DIR>	2015/11/23 08:54	>
<input type="checkbox"/>	00010		O00010.nc	130 B	2015/11/23 08:54	
<input checked="" type="checkbox"/>	00030		O00030.nc	67 B	2015/11/23 08:54	*
<input type="checkbox"/>	00035		O00035.nc	98 B	2015/11/23 08:54	
<input type="checkbox"/>	00045		NEXTGENTe...	15 B	2015/11/23 08:54	
<input type="checkbox"/>	09001 (ALIAS M89)		O9001.nc	94 B	2015/11/23 08:54	

CHECK MARK SELECTION

The check box column on the far left of the file display lets you select multiple files.

Press ENTER to place a check mark in the file's check box. Highlight another file and press ENTER again to put a check mark in that file's check box. Repeat this process until you have selected all the files you want to select.

You can then do an operation (usually copy or delete) on all those files at the same time. Each file that is part of your selection has a check mark in the check box. When you choose an operation, the control does that operation on all the files with check marks.

For example, if you want to copy a set of files from the machine memory to a USB memory device, you will put a check mark on all of the files that you want to copy, then press F2 to start the copy operation.

To delete a set of files, put a check mark on all of files you want to delete, then press DELETE to start the delete operation.

NOTE: A check-mark selection only marks the file for further operation; it does not make the program active.

NOTE: If you have not selected multiple files with check marks, the control does operations only on the currently highlighted directory or file. If you have selected files, the control does operations only on the selected files and not on the highlighted file, unless it is also selected.

SELECT THE ACTIVE PROGRAM

Highlight a program in the memory directory, then press SELECT PROGRAM to make the highlighted program active.

The active program has an asterisk (*) in the far-right column in the file display. It is the program that runs when you press CYCLE START in OPERATION: MEM mode. The program is also protected from deletion while it is active.

CREATE A NEW PROGRAM

Press INSERT to create a new file in the current directory. The CREATE NEW PROGRAM popup menu shows on the screen:

Create New Program Popup Menu Example: [1] Program O number field, [2] File Name field, [3] File comment field.

Enter the new program information in the fields. The Program O number field is required; the File Name and File comment are optional. Use the UP and DOWN cursors to move between the menu fields.

Press **UNDO** at any time to cancel program creation.

Program O number (required for files created in Memory): Enter a program number up to (5) digits long. The control adds the letter O automatically. If you enter a number shorter than (5) digits, the control adds leading zeros to the program number to make it (5) digits long; for example, if you enter 1, the control adds zeros to make it 00001.

The screenshot shows a 'Create New Program' dialog box. It has a blue title bar. Inside, there are three text input fields. The first is labeled 'O Number*' and has a '1' next to it. The second is labeled 'File Name*' and has a '2' next to it. The third is labeled 'File comment' and has a '3' next to it. Below these fields is the text 'Enter an O number or file name'. At the bottom, there are two buttons: 'Enter [ENTER]' and 'Exit [UNDO]'.

NOTE: note: Do not use O09XXX numbers when you create new programs. Macro programs often use numbers in this block and overwriting them may cause machine functions to malfunction or stop working.

File Name (optional): Type a filename for the new program. This is the name the control uses when you copy the program to a storage device other than memory.

File comment (optional): Type a descriptive program title. This title goes into the program as a comment in the first line with the O number.

Press ENTER to save your new program. If you specified an O number that exists in the current directory, the control gives the message File with O Number nnnnn already exists. Do you want to replace it? Press ENTER to save the program and overwrite the existing program, press CANCEL to return to the program name popup, or press UNDO to cancel.

EDIT A PROGRAM

Highlight a program, and then press **ALTER** to move the program into the program editor.

The program has the designation E in the far-right column of the file display list when it is in the editor, unless it is also the active program.

You can use this function to edit a program while the active program runs. You can edit the active program, but your changes do not take effect until you save the program and then select it again in the device manager menu.

COPY PROGRAMS

This function lets you copy programs to a device or a different directory.

To copy a single program, highlight it in the device manager program list and press **ENTER** to assign a check mark. To copy multiple programs, check-mark all the programs you want to copy.


Press **F2** to start the copy operation.

The Select Device popup appears.

Select Device

Use the cursor arrow keys to select the destination directory. **RIGHT** cursor to enter the chosen directory.

Press **ENTER** to complete the copy operation, or press **CANCEL** to return to the device manager.




CREATE / SELECT PROGRAMS FOR EDITING

You use the Device Manager (LIST PROGRAM) to create and select programs for editing. Refer to the CREATE, EDIT, COPY A PROGRAM tab to create a new program.

PROGRAM EDIT MODES

The Haas control has (2) program edit modes: The program editor or manual data input (MDI). You use the program editor to make changes to numbered programs stored in an attached memory device (machine memory, USB, or net share). You use MDI mode to command the machine without a formal program.

The Haas control screen has (2) program edit panes: The Active Program / MDI pane, and the Program Generation pane. The Active Program / MDI pane is on the left side of the screen in all display modes. The Program Generation pane appears only in EDIT mode.



Example Edit Panes.

[1] Active Program / MDI Pane,

[2] Program Edit Pane,

[3] Clipboard Pane

BASIC PROGRAM EDITING

This section describes the basic program editing functions. These functions are available when you edit a program.

1) To write a program, or make changes to a program:

To edit a program in MDI, press MDI. This is EDIT: MDI mode. The program is displayed on the Active pane.

To edit a numbered program, select it in the Device Manager (LIST PROGRAM), then press EDIT. This is EDIT: EDIT mode. The program is displayed in the Program Generation pane.

2) To highlight code:

Use the cursor arrow keys or the jog handle to move the highlight cursor through the program.

You can interact with single pieces of code or text (cursor highlighting), blocks of code, or multiple blocks of code (block selection). Refer to the Block Selection section for more information.

3) To add code to the program:

- Highlight the code block you want the new code to follow.
- Type the new code.
- Press INSERT. Your new code appears after the block you highlighted.

4) To replace code:

- Highlight the code you want to replace.
- Type the code you want to replace the highlighted code with.
- Press ALTER. Your new code takes the place of the code you highlighted.

5) To remove characters or commands:

- Highlight the text you want to delete.
- Press DELETE. The text that you highlighted is removed from the program.

6) Press UNDO to reverse up to the last (40) changes.

NOTE: You cannot use UNDO to reverse changes that you made if you exit EDIT: EDIT mode.

NOTE: In EDIT: EDIT mode, the control does not save the program as you edit. Press MEMORY to save the program and load it into the Active Program pane.

BLOCK SELECTION

When you edit a program, you can select single or multiple blocks of code. You can then copy and paste, delete, or move those blocks in one step.

To select a block:

- Use the cursor arrow keys to move the highlight cursor to the first or last block in your selection.

NOTE: You can start a selection at the top block or the bottom block, and then move up or down as appropriate to complete your selection.

NOTE: You cannot include the program name block in your selection. The control gives the message GUARDED CODE.

- Press F2 to start your selection.
- Use the cursor arrow keys or the jog handle to expand the selection.
- Press F2 to complete the selection.

ACTIONS WITH A BLOCK SELECTION

After you make a text selection, you can copy and paste it, move it, or delete it.

NOTE: These instructions assume you have already made a block selection as described in the Block Selection section.

NOTE: These are actions available in MDI and the Program Editor. You cannot use UNDO to reverse these actions.

1) To copy and paste the selection:

- Move the cursor to the location where you want to put a copy of the text.
- Press ENTER.

The control puts a copy of the selection on the next line after the cursor location.

NOTE: The control does not copy the text to the clipboard when you use this function.

2) To move the selection:

- Move the cursor to the location where you want to move the text.
- Press ALTER.

The control removes the text from its current location and puts it in the line after the current line.

3) Press DELETE to delete the selection.

PART SETUP

Correct work holding is very important for safety, and to get the machining results that you want. There are many work holding options for different applications. Contact your HFO or work holding dealer for guidance.

JOG MODE

Jog mode allows you to jog each of the axes to a desired location. Before jogging the axes it is necessary to home (beginning axes reference point) the axes.

To enter jog mode: 1. Press [handle jog]. 2. Pick an increment speed to be used while in jog mode ([.0001], [.001], [.01] or [.1]). 3. Press the desired axis ([+x], [-x], [+z], or [-z]) and either press and hold these axis jog keys or use the [handle jog] control to move the selected axis.

TOOL OFFSETS

The tool offset behavior has been modified on Haas machines in the following ways:

By default tool offsets will now always be applied, unless a G49/H00 (Mill) or Txx00 offset (Lathe) is explicitly specified.

Press the **[OFFSET]** button to view the tool offset values. The tool offsets can be entered manually or automatically with a probe. The list below will shows how each offset setting works.

1. Active Tool: - This tells you which position is active turret.

2. Tool Offset (T) - This is the list of available tool offsets. There is a maximum of 99 tool offsets available.

3. Turret Location- This column is used to help the operator remember which tool is on the turret station. This is useful when you have a tool holder that has tools mounted on the front and on the back. You want to remember what offset each of the tools is using and where it is located.

Tool Offset	Turret Location	X Geometry	Z Geometry	Radius Geometry	Tip Direction
1	0	0.	0.	0.	0: None
2	0	0.	0.	0.	0: None
3	0	0.	0.	0.	0: None
4	0	0.	0.	0.	0: None
5	0	0.	0.	0.	0: None
6	0	0.	0.	0.	0: None
7	0	0.	0.	0.	0: None
8	0	0.	0.	0.	0: None
9	0	0.	0.	0.	0: None
10	0	0.	0.	0.	0: None
11	0	0.	0.	0.	0: None
12	0	0.	0.	0.	0: None
13	0	0.	0.	0.	0: None
14	0	0.	0.	0.	0: None
15	0	0.	0.	0.	0: None
16	0	0.	0.	0.	0: None
17	0	0.	0.	0.	0: None
18	0	0.	0.	0.	0: None

Enter A Value

X DIAMETER MEASURE X Diameter Measure F1 Set Value ENTER Add To Value F4 Work Offset

4. X and Z Geometry - Each offset contains values for the distance from machine zero to the tip.

5. Radius Geometry - This offset is used to compensate for the radius on the tool tip when cutter compensation is used. Check the radius specification on the tool inserts and enter the value on this offset.

6. Tip Direction - Use this to set the direction of the tool tip when cutter compensation is used. Press **[F1]** to view the options.

7. These functions buttons allow you to set the offset values. Pressing **[F1]** enters the number in the selected column. Entering a value and pressing **[ENTER]** adds the amount entered to the number in the selected column.

8. X and Z Wear Geometry -

The values entered here are intended for minute adjustments to offset that are required to compensate for normal wear during the course of a job.

9. Radius Wear - The values entered here are intended for minute adjustments to offset that are required to compensate for normal wear during the course of a job.

8

Offsets

9

Tool

Work

Active Tool: 0

Tool Offset	X Geometry Wear	Z Geometry Wear	Radius Wear
1	0.	0.	0.
2	0.	0.	0.
3	0.	0.	0.
4	0.	0.	0.
5	0.	0.	0.
6	0.	0.	0.
7	0.	0.	0.
8	0.	0.	0.
9	0.	0.	0.
10	0.	0.	0.
11	0.	0.	0.
12	0.	0.	0.
13	0.	0.	0.
14	0.	0.	0.
15	0.	0.	0.
16	0.	0.	0.
17	0.	0.	0.
18	0.	0.	0.

Enter A Value

X
DIAMETER
MEASURE

 X Diameter Measure

F1

 Set Value

ENTER

 Add To Value

F4

 Work Offset

10. Tool Type - This column is used by the control to decide which probe cycle to use to probe this tool. Press **[F1]** to view the options.

11. Tool Material - This column is used for calculations by the VPS feeds and speeds library. Press **[F1]** to view the options.

10

Offsets

11

Tool

Work

Active Tool: 0

Tool Offset	Tool Type	Tool Material
1	None	User
2	None	User
3	None	User
4	None	User
5	None	User
6	None	User
7	None	User
8	None	User
9	None	User
10	None	User
11	None	User
12	None	User
13	None	User
14	None	User
15	None	User
16	None	User
17	None	User
18	None	User

Enter A Value

X
DIAMETER
MEASURE

 X Diameter Measure

F1

 Set Value

F4

 Work Offset

12. Live Tool Radius - This offset is used to compensate for the radius on the live tool tip. Check the radius specification on the tool inserts and enter the value on this offset.

13. Live Tool Wear - The values entered here are intended for minute adjustments to offset that are required to compensate for normal wear during the course of a job.

14. Flutes - When this column is set to the correct value, the control can calculate the correct Chip Load value displayed at the Main Spindle screen. The VPS feeds and speeds library will also use these values for calculations.

Note: The values set on the Flute column will not affect the operation of the probe.

15. Actual Diameter - This column is used by the control to calculate the correct Surface Speed value displayed at the Main Spindle screen.

Offsets


12
13
14
15

Tool Work

Active Tool: 0

Tool Offset	Live Tool Radius	Live Tool Wear	Flutes	Actual Diameter
1	0.	0.	0	0.
2	0.	0.	0	0.
3	0.	0.	0	0.
4	0.	0.	0	0.
5	0.	0.	0	0.
6	0.	0.	0	0.
7	0.	0.	0	0.
8	0.	0.	0	0.
9	0.	0.	0	0.
10	0.	0.	0	0.
11	0.	0.	0	0.
12	0.	0.	0	0.
13	0.	0.	0	0.
14	0.	0.	0	0.
15	0.	0.	0	0.
16	0.	0.	0	0.
17	0.	0.	0	0.
18	0.	0.	0	0.

Enter A Value


X Diameter Measure

F1 Set Value

ENTER Add To Value

F4 Work Offset

16. Approximate X and Z -

This column is used by the ATP or Tool Setting Probe. The value in this field tells the probe the approximate position of the tool being probed.

17. Approximate Radius -

This column is used by the ATP probe. The value in the field tells the probe the approximate radius of the tool.

18. Edge Measure Height -


This column is used by the ATP probe. The value in this field is the distance below the tip of the tool that the tool needs to move, when the edge is probed. Use this setting when you have a tool with a large radius or when you are probing a diameter on a chamfer tool.

19. Tool Tolerance - This column is used by the probe. The value in this field is used for checking tool breakage and wear detection. Leave this field blank if you are setting the length and diameter on the tool.

20. Probe Type - This column is used by the probe. You can select the probe routine you want to perform on this tool. Press [**X DIAMETER MEASURE**] to view the options.

Tool		Offsets				
Work		16	17	18	19	20
Active Tool: 0						
Tool Offset	Approximate X	Approximate Z	Approximate Radius	Edge Meas... Height	Tool Tolerance	Probe Type
1	0.	0.	0.	0.	0.	None
2	0.	0.	0.	0.	0.	None
3	0.	0.	0.	0.	0.	None
4	0.	0.	0.	0.	0.	None
5	0.	0.	0.	0.	0.	None
6	0.	0.	0.	0.	0.	None
7	0.	0.	0.	0.	0.	None
8	0.	0.	0.	0.	0.	None
9	0.	0.	0.	0.	0.	None
10	0.	0.	0.	0.	0.	None
11	0.	0.	0.	0.	0.	None
12	0.	0.	0.	0.	0.	None
13	0.	0.	0.	0.	0.	None
14	0.	0.	0.	0.	0.	None
15	0.	0.	0.	0.	0.	None
16	0.	0.	0.	0.	0.	None
17	0.	0.	0.	0.	0.	None
18	0.	0.	0.	0.	0.	None

Enter A Value


 Automatic Probe Opti... **F1** Set Value **ENTER** Add To Value **F4** Work Offset

SET A TOOL OFFSET

The next step is to touch off the tools. Doing this defines the distance from the tip of the tool to the side of the part. This procedure requires the following:

- An O.D. Turning Tool
- A work piece that fits in the chuck jaws
- A measuring tool to inspect the workpiece diameter

For information on setting up Live tools, refer to Programming Live Tooling section for more information.




1. Press [OFFSET]. Press [HANDLE JOG].

2. Load an O.D. turning tool into the tool turret. Press [NEXT TOOL] [F] until it is the current tool.

3. Clamp the workpiece in the spindle.

4. Press [.1/100] [B]. The axis selected moves at a fast rate when the handle is turned.

5. Close the lathe door. Type 50 and press [FWD] for the spindle to start.



6. Use the turning tool loaded in station 1 to make a small cut on the diameter of the material clamped in the spindle. Approach the part carefully and feed slowly during the cut.

7. After the small cut is done, jog away from the part using Z-Axis. Move far enough away from the part so that you can take a measurement with your measuring tool.

8. Press Spindle [STOP] and open the door.

9. Use the measuring tool to measure the cut made on the workpiece.

- 10.** Press [X DIAMETER MEASURE] [D] to record the X-axis position in the offset table.
- 11.** Type the workpiece diameter and press [ENTER] to add it to the X-axis offset. The offset that corresponds to the tool and turret station is recorded.
- 12.** Close the lathe door. Type 50 and press [FWD] for the spindle to start.
- 13.** Use the turning tool loaded in station 1 to make a small cut on the face of the material clamped in the spindle. Approach the part carefully and feed slowly during the cut.
- 14.** After the small cut is done, jog away from the part using X-axis. Move far enough away from the part so that you can take a measurement with your measuring tool.
- 15.** Press [Z FACE MEASURE] (E) to record the current Z position in the offset table.
- 16.** The cursor moves to the Z-axis location for the tool.
- 17.** Repeat all of the previous steps for each tool in the program. Do tool changes at a safe location with no obstructions.

WORK OFFSETS

Press the OFFSET, then the F4 to view the work offset values. The work offsets can be entered manually or automatically with a probe. The list below will show how each work offset setting works.

1) G Code - This column displays all the available work offset G-codes. For more information on these work offsets, refer to the G52 Set Work Coordinate System (Group 00 or 12), G54 Work Offsets, G92 Set Work Coordinate Systems Shift Value (Group 00).

2) X, Y, Z, Axis - This column displays the work offset value for each axis. If rotary axis are enabled the offsets for these will be displayed on this page.

3) Work Material - This column is used by the VPS feeds and speeds library.

4) These functions buttons allow you to set the offset values. Type in the desired work offset value and press **[F1]** to set the value. Press **[F3]** to set a probing action. Press **[F4]** to toggle from work to tool offset tab. Type in a value and press Enter to add to the current value.

Set a Work Offset

Your CNC control programs all move from Part Zero, a user-defined reference point. To set Part Zero:

1. Press **[MDI/DNC]** to select Tool #1.
2. Enter T1 and press **[TURRET FWD]**.
3. Jog X and Z until the tool just touches the face of the part.
4. Press **[OFFSET]** until the Work Zero Offset display is active. Highlight the Z Axis column and G-code row that you want to use (G54 recommended).
5. Press **[Z FACE MEASURE]** to set part zero.

Offsets

Tool Work

1 2 3

Axes Info

G Code	X Axis	Y Axis	Z Axis	Work Material
G52	0.	0.	0.	No Material Selected
G54	0.	0.	0.	No Material Selected
G55	0.	0.	0.	No Material Selected
G56	0.	0.	0.	No Material Selected
G57	0.	0.	0.	No Material Selected
G58	0.	0.	0.	No Material Selected
G59	0.	0.	0.	No Material Selected
G154 P1	0.	0.	0.	No Material Selected
G154 P2	0.	0.	0.	No Material Selected
G154 P3	0.	0.	0.	No Material Selected
G154 P4	0.	0.	0.	No Material Selected
G154 P5	0.	0.	0.	No Material Selected
G154 P6	0.	0.	0.	No Material Selected
G154 P7	0.	0.	0.	No Material Selected
G154 P8	0.	0.	0.	No Material Selected
G154 P9	0.	0.	0.	No Material Selected
G154 P10	0.	0.	0.	No Material Selected
G154 P11	0.	0.	0.	No Material Selected

4

F1 To view options. **F3** Probing Actions **F4** Tool Offsets

Enter A Value **ENTER** Add To Value

MACHINE POWER-ON


This section tells you how to power-on a machine and establish the axis home positions. Before you do this procedure, make sure that possible crash areas, such as the tool probe, parts catcher, tailstock, tool turret, and secondary spindle, are clear.

Note: Some machines have a different Zero Return behavior at Power On. See link below for more information.

[Restore Axis Position on Power Up](#)

1 Press **POWER ON**. After the boot sequence, the display shows the startup screen.

The startup screen gives basic instructions to start the machine. Press **CANCEL** to dismiss the screen.



Turn **EMERGENCY STOP** to the right to reset it.

Press **RESET** to clear the startup alarms. If you cannot clear an alarm, the machine may need service.


Contact your Haas Factory Outlet (HFO) for assistance.

If your machine is enclosed, close the doors.

Press **POWER UP**

2 WARNING: Before you do the next step, remember that on some models motion begins immediately when you press POWER UP. Make sure the motion path is clear. Stay away from the spindle, machine table, and tool changer. On some models a Power Up box will be displayed. This box will allow you to zero return the machine manually.

WARNING: ST-10/15 with sub spindle and live tooling the machine clearances are very tight. To zero return it, do these steps:



Press **Hand Jog** to move the turret to a safe location.

Press **T** to zero return the tool turret.

Press **MDI** then **ATC FWD** or **ATC REV** to index the turret so that the short tool faces the spindles.

NOTE: If you get a message: Machine is Not Zeroed! make sure that setting 325 Manual Mode Enabled is set to On.

Zero return the other axis. Press the axis letter followed by the single button.

3 The control is now in **OPERATION:MEM** mode. You can now press **CYCLE START** to run the active program, or you can use other control functions.

SCREEN CAPTURE

The control can capture and save an image of the current screen to an attached USB device or the User Data memory.

Enter a filename if desired. If no filename is entered, the system will use the default filename (see note).

Press SHIFT.

Press F1.

NOTE: The control uses the default filename snapshot#.png. The # starts from 0 and increments each time you capture a screen. This counter resets at power off. Screen captures that you take after a power cycle overwrite previous screen captures that have the same filename on the User Data memory.

Result: The control saves the screen capture to your USB device or control memory. The message Snapshot saved to USB or Snapshot saved to User Data appears when the process finishes.

ERROR REPORT

The control can generate an error report that saves the state of the machine that is used for analysis. This is useful when helping the HFO troubleshoot an intermittent problem.

1. Press SHIFT.
2. Press F3.

NOTE: Be sure to always generate the error report with the alarm or the error is active.

Result: The control saves the error report to your USB device or control memory. The error report is a zip file that includes a screen capture, the active program, and other information used for diagnostics. Generate this error report when an error or an alarm occurs. E-mail the error report to your local Haas Factory Outlet.

BASIC PROGRAM SEARCH

You can use this function to quickly find code in a program.

NOTE: This is a quick-search function that finds the first match in the search direction that you specify. You can use the Editor for a more full-featured search. Refer to Chapter 6.5 for more information on the Editor search function.

NOTE: This is a quick-search function that finds the first match in the search direction that you specify. You can use the Editor for a more full-featured search. Refer to The Search Menu for more information on the Editor search function.

1. Type the text you want to find in the active program.
2. Press the UP or DOWN cursor arrow key.

Result:


The UP cursor arrow key searches from the cursor position to the start of the program. The DOWN cursor arrow key searches to the end of the program. The control highlights the first match.

NOTE: Putting your search term within parentheses (), will search only within comment lines.

LOCATE THE LAST PROGRAM ERROR

Starting in software version **100.19.000.1100** the control can find the last error in a program.

Press **SHIFT + F4** to display the last line of G-code that generated the error.



The purpose of Safe Run is to reduce damage to the machine in the event of a crash. It does not prevent crashes, but it raises an alarm sooner and backs off from the crash location.

NOTE: The Safe Run feature is available starting in software version 100.19.000.1300.

NOTE: If the machine is equipped with a spindle head accelerometer, and when safe mode is enabled and active (i.e. during rapids), the accelerometer alarm behavior will be suppressed so the machine can do the normal back off behavior, then the **9941 Alarm** will generate. The G force value will still be recorded at the time of the event.

Safe Run Supported Machines

- VF-1 through VF-5
- VM-2/3
- UMC-500/750/1000
- All DM's
- All DT's
- All TM's
- ST-10 through ST-35

Common causes for crashes are:

- Incorrect tool offsets.
- Incorrect work offsets.
- Wrong tool in the spindle.

NOTE: The Safe Run feature will only detect a crash in handle jog and rapid (G00), it will not detect a crash in a feed move.

Safe Run does the following:

Slow down the speed of the motion.

Increases the position error sensitivity.


When a crash is detected, the control will immediately reverse the axis by a small amount. This will prevent the motor from continuing to drive into the object it has crashed into as well as relieve pressure from the crash itself. After Safe Run has detected a crash, you should be able to easily fit a piece of paper between the two surfaces that crashed.

NOTE: Safe Run is intended for running a program for the first time after writing or changing it. It is not recommended to run a reliable program with Safe Run, as it increases cycle time significantly. The tool may break and the work piece may still be damaged in a crash.

Safe Run is active during jogging as well. Safe Run can be used during job setup to protect against accidental crashes due to operator error.

If your machine supports Safe Run, you will see a new icon in MDI with the text F3 Activate Safe Run [1]. Press F3 to turn Safe Run on/off. Safe Run Active state is noted by a water mark [2] in the program panel. It is only active during rapid motions. Rapid motions include G00, Home G28, moving to tool changes, and the non-machining motions of canned cycles. Any machining motion such as a feed or tap will not have safe mode active.

Safe Run is not active during feeds due to the nature of crash detection. Cutting forces cannot be discerned from crashes.



When a crash is detected, all motion is brought to a stop, an alarm [1] is generated, and a popup [2] is generated letting the operator know that a crash was detected, and which axis it was detected on. This alarm can be cleared by reset.

In certain cases, the pressure against the part may not have been relieved by the Safe Run back-off. In the worst case, an additional crash may be generated after you have reset the alarm. If this happens, turn Safe Run off and jog the axis away from the crash location.



RUN-STOP-JOG-CONTINUE

This feature lets you stop a running program, jog away from the part, and then start the program again.

1 Press **FEED HOLD**.

Axis motion stops. The spindle continues to turn.

2 Press X, Y, Z, or an installed Rotary Axis (A for A Axis, B for B Axis, and C for C Axis), then press **HANDLE JOG**. The control stores the current X, Y, Z, and rotary axes positions.

3 The control gives the message Jog Away and displays the Jog Away icon. Use the jog handle or jog keys to move the tool away from the part. You can start or stop the spindle with FWD, REV, or STOP. You can command optional Through Spindle Coolant on and off with the AUX CLNT key (you must stop the spindle first). Command optional Through Tool Air Blast on and off with SHIFT + AUX CLNT keys. Command Coolant on and off with the COOLANT key. Command the Auto Air Gun / Minimum Quantity Lubrication options with SHIFT + COOLANT keys. You can also release the tool to change inserts.

CAUTION: When you start the program again, the control uses the previous offsets for the return position. Therefore, it is unsafe and not recommended to change tools and offsets when you interrupt a program.

4 Jog to a position as close as possible to the stored position, or to a position where there is an unobstructed rapid path back to the stored position.

5 Press MEMORY or MDI to return to run mode. The control gives the message Jog Return and displays the Jog Return icon. The control continues only if you return to the mode that was in effect when you stopped the program.

6 Press CYCLE START. The control rapids X, Y, and rotary axes at 5% to the position where you pressed FEED HOLD. It then returns the Z Axis. If you press FEED HOLD during this motion, axis motion pauses and the control gives the message Jog Return Hold. Press CYCLE START to resume the Jog Return motion. The control goes into a feed hold state again when the motion is finished.

CAUTION: The control does not follow the same path that you used to jog away.

7 Press CYCLE START again, and the program resumes operation.

CAUTION: If Setting 36 is ON, the control scans the program to make sure the machine is in the correct state (tools, offsets, G- and M-codes, etc.) to safely continue the program. If Setting 36 is OFF, the control does not scan the program. This can save time, but it could cause a crash in an unproven program.

GRAPHICS MODE

A safe way to troubleshoot a program is to press GRAPHICS to run it in graphics mode. No movement occurs on the machine, instead the movement is illustrated on the screen.

1) Axis Planes Press 1 to view the graphics in G17 plane, press 2 for G18 plane or press 3 to view in G19 plane.

2) Key Help Area The lower-left part of the graphics display pane is the function key help area. This area shows you the function keys that you can use, and a description of what they do.

3) Locator Window The lower-right part of the pane displays the simulated machine table area, and it shows where the simulated view is zoomed and focused.

4) Graphics Speed Press f3 or f4 to run the desired graphics speed.

5) Tool Path Window The large window in the center of the display gives a simulated view of the work area. It displays a cutting tool icon and simulated tool paths.


NOTE: Feed motion appears as a black line. Rapid moves appear as a green line. Drill cycle locations appear with an X.

NOTE: If Setting 253 is ON, the tool diameter is shown as a thin line. If it is OFF, the tool diameter specified in the Tool Offsets Diameter Geometry table is used.

6) Zoom Press F2 to display a rectangle (zoom window) that shows the area that the zoom operation will move to. Use PAGE DOWN to decrease the size of the zoom window (zoom in) and use PAGE UP to increase the size of the zoom window (zoom out). Use the cursor arrow keys to move the zoom window to the location you want to zoom, and press ENTER to complete the zoom. The control scales the tool path window to the zoom window. Run the program again to display the tool path. Press F2 and then HOME to expand the Tool Path window to cover the entire work area.

7) Z-Axis Part Zero Line The horizontal line on the Z-Axis bar at the top-right corner of the graphics screen gives the position of the current Z-axis work offset plus the length of the current tool. While a program simulation runs, the shaded portion of the bar indicates the depth of the simulated Z-Axis motion relative to the Z-Axis work zero position.

8) Position Pane The position pane displays axis locations just as it would during a live part run



LATHE G-CODES INTRODUCTION

This section gives detailed descriptions of the G-codes that you use to program your machine.

CAUTION: The sample programs in this manual have been tested for accuracy, but they are for illustrative purposes only. The programs do not define tools, offsets, or materials. They do not describe workholding or other fixturing. If you choose to run a sample program on your machine, do so in Graphics mode. Always follow safe machining practices when you run an unfamiliar program.

NOTE: The sample programs in this manual represent a very conservative programming style. The samples are intended to demonstrate safe and reliable programs, and they are not necessarily the fastest or most efficient way to operate a machine. The sample programs use G-codes that you might choose not to use in more efficient programs.

Lathe - G-Codes

G-Code	Description	Group
G00	Rapid Motion Positioning	01
G01	Linear Interpolation Motion	01
G02	CW Circular Interpolation Motion	01
G03	CCW Circular Interpolation Motion	01
G04	Dwell	00
G09	Exact Stop	00
G10	Set Offsets	00
G12	Circular Pocket Milling CW	
G13	Circular Pocket Milling CCW	
G14	Secondary Spindle Swap	17
G15	Secondary Spindle Swap Cancel	17
G17	XY Plane	02
G18	XZ Plane	02
G19	YZ Plane	02
G20	Select Inches	06
G21	Select Metric	06
G28	Return To Machine Zero Point	00
G29	Return From Reference Point	00
G31	Skip Function	00
G32	Thread Cutting	01
G40	Tool Nose Compensation Cancel	07
G41	Tool Nose Compensation (TNC) Left	07
G42	Tool Nose Compensation (TNC) Right	07
G43	Tool Length Compensation + (Add)	08
G50	Spindle Speed Limit	00
G50	Set Global coordinate Offset FANUC	00
G52	Set Local Coordinate System FANUC	00
G53	Machine Coordinate Selection	00
G54	Coordinate System #1 FANUC	12
G55	Coordinate System #2 FANUC	12
G56	Coordinate System #3 FANUC	12

G57	Coordinate System #4 FANUC	12
G58	Coordinate System #5 FANUC	12
G59	Coordinate System #6 FANUC	12
G61	Exact Stop Modal	15
G64	Exact Stop Cancel G61	15
G65	Macro Subprogram Call Option	00
G68	Rotation	16
G69	Cancel G68 Rotation	16
G70	Finishing Cycle	00
G71	O.D./I.D. Stock Removal Cycle	00
G72	End Face Stock Removal Cycle	00
G73	Irregular Path Stock Removal Cycle	00
G74	End Face Grooving Cycle	00
G75	O.D./I.D. Grooving Cycle	00
G76	Threading Cycle, Multiple Pass	00
G80	Canned Cycle Cancel	09
G81	Drill Canned Cycle	09
G82	Spot Drill Canned Cycle	09
G83	Normal Peck Drilling Canned Cycle	09
G84	Tapping Canned Cycle	09
G85	Boring Canned Cycle	09
G86	Bore and Stop Canned Cycle	09
G89	Bore and Dwell Canned Cycle	09
G90	O.D./I.D. Turning Cycle	01
G92	Threading Cycle	01
G94	End Facing Cycle	01
G95	Live Tooling Rigid Tap (Face)	09
G96	Constant Surface Speed On	13
G97	Constant Surface Speed Off	13
G98	Feed Per Minute	10
G99	Feed Per Revolution	10
G100	Disable Mirror Image	00
G101	Enable Mirror Image	00
G103	Limit Block Lookahead	00
G105	Servo Bar Command	09
G107	G107 Cylindrical Mapping	00
G110	Coordinate System #7	12
G111	Coordinate System #8	12
G112	XY to XC Interpolation	04
G113	Cancel G112	04
G114	Coordinate System #9	12
G115	Coordinate System #10	12
G116	Coordinate System #11	12
G117	Coordinate System #12	12
G118	Coordinate System #13	12
G119	Coordinate System #14	12

G120	Coordinate System #15	12
G121	Coordinate System #16	12
G122	Coordinate System #17	12
G123	Coordinate System #18	12
G124	Coordinate System #19	12
G125	Coordinate System #20	12
G126	Coordinate System #21	12
G127	Coordinate System #22	12
G128	Coordinate System #23	12
G129	Coordinate System #24	12
G154	Select Work Coordinates P1-99	12
G156	Broaching Canned Cycle	09
G167	Modify Setting	00
G170	G170 Cancel G171/G172	20
G171	G171 Radius Programming Override	20
G172	G172 Diameter Programming Override	20
G184	Reverse Tapping Canned Cycle For Left Hand Threads	09
G186	Reverse Live Tool Rigid Tap (For Left Hand Threads)	09
G187	Accuracy Control	00
G195	Forward Live Tool Radial Tapping (Diameter)	09
G196	Reverse Live Tool Radial Tapping (Diameter)	09
G198	Disengage Synchronous Spindle Control	00
G199	Engage Synchronous Spindle Control	00
G200	Index on the Fly	00
G211	Manual Tool Setting	-
G212	Auto Tool Setting	-
G234	Tool Center Point Control (TCPC)	08
G241	Radial Drill Canned Cycle	09
G242	Radial Spot Drill Canned Cycle	09
G243	Radial Normal Peck Drilling Canned Cycle	09
G245	Radial Boring Canned Cycle	09
G246	Radial Bore and Stop Canned Cycle	09
G249	Radial Bore and Dwell Canned Cycle	09
G250	Cancel Scaling	11
G251	Scaling	11
G254	Dynamic Work Offset (DWO)	23
G255	Cancel Dynamic Work Offset (DWO)	23
G266	Visible Axes Linear Rapid %Motion	00
G268	Enable Feature Coordinate System	02
G269	Disable Feature Coordinate System	02
G390	Absolute Position Command	03
G391	Incremental Position Command	03

LATHE M-CODES INTRODUCTION

This page gives detailed descriptions of the M-codes that you use to program your machine.

CAUTION: The sample programs in this manual have been tested for accuracy, but they are for illustrative purposes only. The programs do not define tools, offsets, or materials. They do not describe workholding or other fixturing. If you choose to run a sample program on your machine, do so in Graphics mode. Always follow safe machining practices when you run an unfamiliar program.

NOTE: The sample programs in this manual represent a very conservative programming style. The samples are intended to demonstrate safe and reliable programs, and they are not necessarily the fastest or most efficient way to operate a machine. The sample programs use G-codes that you might choose not to use in more efficient programs.

M-codes are miscellaneous machine commands that do not command axis motion. The format for an M-code is the letter M followed by two to three digits; for example M03. Only one M-code is allowed per line of code. All M-codes take effect at the end of the block.

Lathe - M-Codes

M- Code	Description
M00	Stop Program
M01	Optional Stop Program
M02	Program End
M03	Spindle On Fwd
M04	Spindle On Rev
M05	Spindle Stop
M08 / M09	Coolant On / Off
M10 / M11	Chuck Clamp / Unclamp
M12 / M13	Auto Jet Air Blast On / Off (Optional)
M14 / M15	Main Spindle Brake On /Off (Optional C-Axis)
M17	Turret Rotation Fwd
M18	Turret Rotation Rev
M19	Orient Spindle (Optional)
M21	Tailstock Advance (Optional)
M22	Tailstock Retract (Optional)
M23	Chamfer Out of Thread On
M24	Chamfer Out of Thread Off
M30	End of Program and Reset
M31	Chip Auger Forward (Optional)
M33	Chip Auger Stop (Optional)
M35	Parts Catcher Part-Off Position
M36	Parts Catcher On (Optional)
M37	Parts Catcher Off (Optional)
M38 / M39	Spindle Speed Variation On / Off
M41 / M42	Low / High Gear (Optional)
M43	Turret Unlock (Service Use Only)
M44	Turret Lock (Service Use Only)

M51 - M56	Turn On Built-In M-Code Relay
M59	Turn On Output Relay
M61 - M66	M61 - M66 Turn Off Built-In M-Code Relay
M69	Turn Off Output Relay
M78	Alarm if Skip Signal Found
M79	Alarm if Skip Signal Not Found
M85 / M86	Automatic Door Open / Close (Optional)
M88 / M89	High Pressure Coolant On / Off (Optional)
M90 / M91	Fixture Clamp Input On / Off
M95	Sleep Mode
M96	Jump If No Signal
M97	Local Subprogram Call
M98	Subprogram Call
M99	Subprogram Return Or Loop
M104 / M105	Probe Arm Extend / Retract (Optional)
M109	Interactive User Input
M110	Secondary Spindle Chuck Clamp (Optional)
M111	Secondary Spindle Chuck Unclamp (Optional)
M112 / M113	Secondary Spindle Air Blast On / Off (Optional)
M114 / M115	Secondary Spindle Brake On / Off (Optional)
M119	Secondary Spindle Orient (Optional)
M121- M126	M121 - M126 Built-In M-Codes Relays with M-Fin
M129	Turn On M-Code Relay with M-Fin
M130 / M131	Display Media / Cancel Display Media
M133	Live Tool Fwd (Optional)
M134	Live Tool Rev (Optional)
M135	Live Tool Stop (Optional)
M138	Spindle Speed Variation On
M139	Spindle Speed Variation Off
M143	Secondary Spindle Forward (Optional)
M144	Secondary Spindle Reverse (Optional)
M145	Secondary Spindle Stop (Optional)
M146 / M147	Steady Rest Clamp / Unclamp (Optional)
M158 / M159	Mist Condenser On/Off
M170 / M171	Engage 4th Axis Brake / Release 4th Axis Brake
M214 / M215	Live Tool Brake On/Off
M219	Live Tool Orient (Optional)
M299	APL / Part Load / or Program End
M300	M300 - APL/Robot Custom Sequence
M334 / M335	P-Cool Increment / P-Cool Decrement
M373 / M374	Tool Air Blash (TAB) On/OFF
M388 / M389	Through-Spindle Coolant On / Off

LATHE SETTINGS INTRODUCTION

This page gives detailed descriptions of the settings that control the way that your machine works. Inside the **SETTINGS** tab, the settings are organized into groups. Use the **[UP]** and **[DOWN]** cursor arrow keys to highlight a setting group. Press the **[RIGHT]** cursor arrow key to see the settings in a group, . Press the **[LEFT]** cursor arrow key to return to the setting group list.

To quickly access a single setting, make sure the **SETTINGS** tab is active, type the setting number, and then press **[F1]** or, if a setting is highlighted, press the **[DOWN]** cursor.

Some settings have numerical values that fit in a given range. To change the value of these settings, type the new value and press **[ENTER]**. Other settings have specific available values that you select from a list. For these settings, use the **[RIGHT]** cursor to display the choices.

Press **[UP]** and **[DOWN]** to scroll through the options.

Press **[ENTER]** to select the option.

Lathe - Settings

Setting Number	Description
1	Auto Power Off Timer
2	Power Off at M30
4	Graphics Rapid Path
5	Graphics Drill Point
6	Front Panel Lock
8	Prog Memory Lock
9	Dimensioning
10	Limit Rapid at 50%
17	Opt Stop Lock Out
18	Block Delete Lock Out
19	Feedrate Override Lock
20	Spindle Override Lock
21	Rapid Override Lock
22	Can Cycle Delta Z
23	9xxx Progs Edit Lock
28	Can Cycle Act w/o X/Y
29	G91 Non-modal
31	Reset Program Pointer
32	Coolant Override
39	Beep @ M00, M01, M02, M30
42	M00 After Tool Change
43	Cutter Comp Type
44	Min F Radius CC%
45	Mirror Image X Axis
46	Mirror Image Y Axis
47	Mirror Image Z Axis
52	G83 Retract Above R
53	Jog w/o Zero Return
56	M30 Restore Default G

57	Exact Stop Canned X-Y
58	Cutter Compensation
59	Probe Offset X+
60	Probe Offset X-
63	Tool Probe Width
64	Tool Offset Measure Uses Work
71	Default G51 Scaling
72	Default G68 Rotation
73	G68 Incremental Angle
74	9xxx Progs Trace
75	9xxx Progs Single BLK
77	Scale Integer F
80	Mirror Image B Axis
82	Language
83	M30/Resets Overrides
84	Tool Overload Action
85	Maximum Corner Rounding
87	Tool Change Resets Override
88	Reset Resets Override
90	Max Tools To Display
93	Tailstock X Clearance
94	Tailstock Z Clearance
95	Thread Chamfer Size
96	Thread Chamfer Angle
97	Tool Change Direction
99	Thread Minimum Cut
101	Feed Override -> Rapid
102	C Axis Diameter
103	Cyc Start/Fh Same Key
104	Jog Handle to SNGL BLK
105	TailStock Retract Distance
108	Quick Rotary G28
109	Warm-Up Time in Min.
110	Warmup X Distance
111	Warmup Y Distance
112	Warmup Z Distance
113	Tool Change Method
114	Conveyor Cycle Time (minutes)
115	Conveyor On-Time (minutes)
117	G143 Global Offset
118	M99 Bumps M30 Cntrs
119	Offset Lock
120	Macro Var Lock
130	Tap Retract Speed
131	Auto Door
133	Repeat Rigid Tap

142	Offset Chng Tolerance
143	Machine Data Collection Port
144	Feed Override -> Spindle
145	Tailstock At Part For Cycle Start
155	Load Pocket Tables
156	Save Offsets with Program
158	X Screw Thermal Comp%
159	Y Screw Thermal Comp%
160	Z Screw Thermal Comp%
162	Default To Float
163	Disable .1 Jog Rate
165	Ssv Variation (RPM)
166	Ssv Cycle
191	Default Smoothness
196	Conveyor Shutoff
197	Coolant Shutoff
199	Backlight Timer
216	Servo and Hydraulic Shutoff
232	G76 Default P Code
238	High Intensity Light Timer (minutes)
239	Worklight Off Timer (minutes)
240	Tool Life Warning
241	Tailstock Hold Force
242	Air Water Purge Interval
243	Air Water Purge On-Time
245	Hazardous Vibration Sensitivity
247	Simultaneous XYZ Motion in Tool Change
249	Enable Haas Startup Screen
250	Mirror Image C Axis
251	Subprogram Search Location
252	Custom Subprogram Search Location
253	Default Graphics Tool Width
261	DPRNT Store Location
262	DPRNT Destination File Path
263	DPRNT Port
264	Autofeed Step Up
265	Autofeed Step Down
266	Autofeed Minimum Override
267	Exit Jog Mode After Idle Time
268	Second Home Position X
269	Second Home Position Y
270	Second Home Position Z
276	Workholding Input Monitor
277	Lubrication Cycle Interval
281	Chuck Foot Pedal Lock Out
282	Main Spindle Chuck Clamping

283	Chuck Unclamp RPM
284	Cycle Start Allowed With Chuck Unclamped
285	X Diameter Programming
286	Canned Cycle Cut Depth
287	Canned Cycle Retraction
289	Thread Finish Allowance
291	Main Spindle Speed Limit
306	Minimum Chip Clear Time
313	Max User Tavel Limit X
314	Max User Travel Limit Y
315	Max User Travel Limit Z
319	VDI Spindle Center Line X
320	BOT Spindle Center Line X
321	Spindle Center Line Y
322	Foot Pedal Tailstock Alarm
323	Disable Notch Filter
325	Manual Mode Enabled
326	Graphics X Zero Location
327	Graphics Z Zero Location
328	eHandwheel Rapid Limit
329	Main Spindle Jog Speed
330	MultiBoot Selection Time out
331	Sub Spindle Jog Speed
332	Foot Pedal Lockout
333	Probe Offset Z+
334	Probe Offset Z-
335	Linear Rapid Mode
336	Bar Feeder Enable
337	Safe Tool Change Location X
338	Safe Tool Change Location Y
339	Safe Tool Change Location Z
340	Chuck Clamp Delay Time
341	Tailstock Rapid Position
342	Tailstock Advance Distance
343	Sub Spindle SSV Variation
344	Sub Spindle SSV Cycle
345	Sub Spindle Chuck Clamping
346	Sub Spindle Chuck Unclamp RPM
347	Live Tooling SSV Variation
348	Live Tooling SSV Cycle
349	Live Tooling Chuck Clamping
350	Live Tooling Chuck Unclamp RPM
352	Live Tooling Speed Limit
355	Sub Spindle Speed Limit
356	Beeper Volume
357	WarmUp Compensation Cycle Start Idle Time

358	Steady Rest Clamp/Unclamp Delay Time
359	SS Chuck Clamp Delay Time
360	Steady Rest Foot Pedal Lockout
361	Bar Pusher Vent Time
368	Live Tooling Type
372	Parts Loader Type
375	APL Gripper Type
376	Light Curtain Enable
377	Negative Work Offsets
378	Safe Zone Calibrated Geometry Reference Point X
379	Safe Zone Calibrated Geometry Reference Point Y
380	Safe Zone Calibrated Geometry Reference Point X
381	Enable Touchscreen
383	Table Row Size
396	Enable / Disable Virtual Keyboard
397	Press and Hold Delay
398	Header Height
399	Tab Height
403	Change Popup Button Size
409	Default Coolant Pressure
410	Safe Tool Change Location B
413	Main Spindle Load Type
414	Sub Spindle Load Type
416	Media Destination
417	Chuck Unclamp Delay Time
418	SS Chuck Unclamp Delay Time
421	General Orient Angle
422	Lock Graphics Plane
423	Help Text Icon Size
424	Mist Extractor Condenser Time Out

LATHE OTHER EQUIPMENT

Interactive Manuals

Product	Lathe Operator's Manual Supplements	Service Manual
VMT-750	VMT- Interactive Operator's Manual Supplement	N/A
Haas Bar Feeder	Haas Bar Feeder - Interactive Operator's Manual Supplement	Haas Barfeeder - Interactive Service Manual
Lathe APL	Lathe - APL - Interactive Operator's Manual Supplement	Haas Automatic Parts Loader - Interactive Service Manual
Toolroom Lathe	Toolroom Lathe - Interactive Operator's Manual Supplement	N/A
Chucker Lathe	Chucker Lathe - Interactive Operator's Manual Supplement	N/A
Other Equipment	Operator's Manual	Service Manual
Autodoor	N/A	Autodoor - Interactive Service Manual
Haas Air Compressor	Haas Air Compressor - Operators/Service Manual	Haas Air Compressor - Operators/Service Manual
Haas Cobot Package	Haas Cobot Package - Operator's/Service Manual	Haas Cobot Package - Operator's/Service Manual
Haas Laser Engraver	Haas Laser Engraver - Operator's/Service Manual	Haas Laser Engraver - Operator's/Service Manual
Haas Robot Package	Haas Robot Package - Interactive Operator's Manual	Haas Robot Package - Interactive Service Manual
Haas Robot Pallet Loader	Haas Robot Pallet Loader - Operator's/Service Manual	Haas Robot Pallet Loader - Operator's/Service Manual
HSF-325	HSF-325 - Interactive Operator's/Service Manual	HSF-325 - Interactive Operator's/Service Manual
HSF-450	HSF-450 - Interactive Operator's/Service Manual	HSF-450 - Interactive Operator's/Service Manual
HTS400	HTS400 - Interactive Operator's/Service Manual	HTS400 - Interactive Operator's/Service Manual
Haas Tooling and Workholding	N/A	Haas Tooling and Workholding - Interactive Service Manual
Lubrication Systems	N/A	Lubrication Systems - Interactive Service Manual
Chip Removal and Coolant	N/A	Chip Removal and Coolant - Interactive Service Manual
WIPS and WIPS-L	WIPS - Interactive Operator's Manual Supplement	N/A
CAN Bus Systems	N/A	CAN Bus Systems - Interactive Service Manual
Haas Spindle Chiller	Haas Spindle Chiller - Operator's/Service Manual	Haas Spindle Chiller - Operator's/Service Manual